

Roof Tile Division Members (May 2007)

	Company	Head Office	Contact
	* Brikor Roofing	PO Box 884 Nigel 1490	Tel (011) 316 1200 Fax (011) 316 1380
	* Concor Technicrete	PO Box 708 Crown Mines 2025	Tel (011) 495-2200 Fax (011) 495-2489
	Eagle Roof Tiles	PO Box 2104 George 6530	Tel (044) 874-0290 Fax (044) 874-0282
	* Inca Masonry Products	PO Box 3208 Cambridge 5206	Tel (043) 745 1215 Fax (043) 746 1501
	Infraset	Private Bag X1006 Lyttleton 0140	Tel (012) 652 0000 Fax (012) 652 0132
	* Lafarge Roofing South Africa	PO Box 1468 Vereeniging 1930	Tel (016) 430 8000 Fax (016) 430 8068
	* Lafarge Roofing South Africa	PO Box 1468 Vereeniging 1930	Tel (016) 430 8000 Fax (016) 430 8068
	* Marley Roofing	PO Box 127 Olifantsfontein 1665	Tel (011) 316 2121 Fax (011) 316 1498
* CMA Roofing System Licence Holders			



Block D, Lone Creek, Waterfall Office Park
Bekker Road, Midrand
PO Box 168 Halfway House 1685
Telephone+27 11 805 6742
Facsimile +27 11 315 4683
e-mail main.cma@gmail.com
Website www.cma.org.za

CONCRETE
ROOF TILES

TECHNICAL
MANUAL



Preface

This manual has been compiled by the Concrete Manufacturers Association (CMA) to promote good roofing practice. Good roofing practice necessitates correct design and detailing, the use of good quality materials and proper installation procedures. Provided that these are done correctly, a concrete tile roof will provide years of maintenance free service enhancing the aesthetic appeal of the building. This manual has been compiled in compliance with the National Building Regulations, SANS 10062-2003 (Code of Practice for the fixing of concrete roof tiles) and accepted good building practice.

Acknowledgements

The CMA acknowledges the help and assistance from MiTek South Africa (Pty) Ltd and Victor Booth, Consulting Engineer.

CONTENTS

SECTION 1	GENERAL	PAGE
1.1	Typical applications	4
1.2	Product range	18
1.3	Roof forms	20
1.4	Relative performance of standard roofing materials	22
1.5	General information	24
SECTION 2	TECHNICAL DATA	
2.1	Structural data	30
2.2	Physical properties	31
2.3	Underlays	32
2.4	Below minimum pitch specification	35
2.5	Condensation and ventilation	37
2.6	Roof pitch, wind forces and fixing recommendations	39
2.7	Estimating	47
2.8	Tender specification and bill of quantities	51
2.9	General notes	55
SECTION 3	TILING PROCEDURE	
3.1	Inspection before tiling	60
3.2	Setting out for tiling	61
3.3	Loading of the tiles on to the roof	61
3.4	Laying of tiles	62
3.5	Eaves	63
3.6	Valleys	64
3.7	Ridges	66
3.8	Hips	68
3.9	Verges	69
3.10	Abutments and flashings	71
3.11	Inspection after tiling	75

CONTENTS

SECTION 4	DETAILING	PAGE
4.1	Preface	80
4.2	Batten positions	81
4.3	Undertile membrane	82
4.4	Condensation and ventilation	85
4.5	Eaves	86
4.6	Valleys	89
4.7	Ridges	92
4.8	Hips	95
4.9	Verges	97
4.10	Abutments and flashing	99
4.11	Special roofs	101
SECTION 5	TIMBER ROOF CONSTRUCTION	
5.1	General information	106
5.2	Timber quality	106
5.3	Timber specification	107
5.4	Timber treatment	107
5.5	Storage of timber	107
5.6	Roof pitch and wind forces	108
5.7	Undertile membrane for roof tiles	109
5.8	Factory engineered trusses	111
5.9	Site manufactured trusses	112
5.10	Erection of trusses	115
5.11	The use of rafters only as roof supports	117
5.12	Fixing of battens	119
APPENDICES		
	Appendix A	Legend
	Appendix B	Source documents
		121
		122

Concrete Roof Tiles

Section 1 General

Section 1: General

	CONTENTS	PAGE
1.1	Typical applications	4
1.2	Product range	18
1.3	Roof forms	20
1.4	Relative performance of standard roofing materials	22
1.5	General information	24

1.1 Typical Applications: Affordable Housing



Ormonde View, Gauteng



House Khoza, KwaZulu-Natal



Naturena 100 Oaks, Gauteng



Alabama Housing, North West Province



House Zimbali, KwaZulu-Natal



House Schroeder, Gauteng



House Kemp, KwaZulu-Natal



House Swanepoel, Gauteng



Tribunal Gardens, Community Flats, Gauteng



Coastal Manors, Community Flats, KwaZulu-Natal



Lavender Close, Townhouse Complex, Gauteng



Lion Sands, Townhouse Complex, Gauteng

Luxury Housing Complexes



Windsor Crescent, Cluster Houses, KwaZulu-Natal




Lonehill Village, Cluster Houses, Gauteng



Tinza Apartments, Gauteng



Vecchio Village, Apartments, KwaZulu-Natal



The Campus, Office Development, Gauteng



Bryanston Wedge, Office Development, Gauteng



Parks Board Offices, Mpumalanga



IL Villagio, Office Park, Gauteng



Shelanti Chapel, Gauteng



Bayside Church, KwaZulu-Natal



Church of Jesus Christ of Latter Day Saints, Gauteng



Rosebank Union Church, Gauteng



Crawford College, KwaZulu-Natal



Hlabisa Municipality, KwaZulu-Natal



Kwa Mashu Police Station, KwaZulu-Natal



Tembisa Magistrates Court, Gauteng

1.2 Product Range

a) Tile Profiles



Flat Double Roman Profile




Bold Double Roman Profile



Bold Roll Profile



Marseilles Profile



Flat Profile



Double Pan Profile

b) Tile Fittings



Butt Ridge



Hip Starter



Collar Mono Ridge



Rake Verge



Butt Mono Ridge




Taper Ridge




Ventilated Ridge


1.3 Roof Forms




Intersecting hip roof




Intersecting gable roof




Hip to hip




Gable to gable




Dutch hip




Hip gable




Mansard




Split gable




Double monopitch




Parapet gable




Flush roof window




Pyramid (4 sided)




Monopitch / lean to




Sloping dormer




Pyramid (6 sided)




A-frame




Straight dormer



Bali



Double pitch asymmetric



Sloping dormer with sloping cheeks

1.4 Relative Performance of Standard Roofing Materials

Attributes	Concrete Roof tiles	Galvanised iron sheeting	Corrugated fibre cement sheeting	IBR metal sheeting
Comparative cost (including fixing)	0%	+28%	+66%	+62%
Durability	Life time	Reasonable	Reasonable	Reasonable
Life	+50 yrs	+5 yrs	+15 yrs	+5 yrs
Maintenance requirements	Minimal	Minimal	Minimal	Minimal
Aesthetics	Excellent	Poor	Poor	Poor
Hail resistance	Good	Good	Reasonable	Good
Noise resistance	Good	Very poor	Poor	Very poor
Fire resistance	Excellent	Good	Good	Good
Thermal efficiency	Excellent	Poor	Good	Poor
Quality standards	SANS 542-2004	Galvanising – SANS 14713-1999	SANS 685-2005	No SANS spec
Ease of laying	Easy	Easy	Easy	Easy
Ease of repair	Easy	Reasonable	Reasonable	Reasonable
Wind resistance	Good	Reasonable	Reasonable	Reasonable

Pressed metal roof tiles	Fibre cement slate	Natural slate	Thatch	Coloured metal sheeting	Burnt clay roof tiles
+144%	+175%	+360%	+60%	+63%	+300%
Reasonable	Reasonable	Reasonable	Poor	Reasonable	Reasonable
+15 yrs	+15 yrs	+15 yrs	+10 yrs	+10 yrs	+30 yrs
Repaint every 15 yrs	Minimal	Annual service	Over thatch every 10 yrs	Repaint every 10 yrs	Minimal
Reasonable	Good	Excellent	Excellent	Good	Excellent
Good	Poor	Reasonable	Good	Good	Good
Very poor	Fair	Fair	Good	Very poor	Good
Good	Good	Good	Very poor	Good	Excellent
Poor	Good	Good	Excellent	Poor	Good
SANS 1022-2006	SANS 803-2005	No SANS spec	No SANS spec	No SANS spec	No SANS spec
Specialist	Specialist	Specialist	Specialist	Easy	Specialist
Specialist	Specialist	Specialist	Specialist	Reasonable	Specialist
Reasonable	Good	Good	Poor	Reasonable	Good

1.5 General Information

Concrete roof tiles are an outstanding example of a high quality, cost-effective solution for roofing. They have proved their worth over many years of trouble-free use, providing maximum protection against the elements. Concrete roof tiles are manufactured in an extensive range of profiles, colours and finishes which enhance the visual appearance of any roof and provide designers with a wide scope for expression.

a) Manufacture

Concrete roof tiles are manufactured from selected raw materials such as washed graded sand, portland cement, inorganic pigments and water. The tiles are extruded under pressure resulting in a product of high quality. The strength of concrete roof tiles increases with age.

b) Quality standards

Concrete roof tiles manufactured by members

of the Concrete Manufacturers Association meet the requirements of SANS 542-2004 Standard specification for the manufacture of concrete roofing tiles. They are manufactured in accordance with the SANS ISO 9002 Quality Management System.

c) Surface coatings

Concrete roof tiles are manufactured in a vast range of finishes which will vary from one manufacturer to another. Surface finishes for tiles are categorised in accordance with SABS specifications. All surface coatings are applied under factory controlled conditions.

d) Colours

Large selections of standard colours are available. Fittings are available in colours to match tiles. For further information, colour charts, special colours and samples, contact the manufacturers.

Table 1: Categorisation of tiles in respect of body colour and surface coatings

Category	Body Colour	Surface Coating
1	No	No
2	No	Yes
3	Yes	No
4	Yes	Yes

Category 1. Plain concrete tiles. No body colour. No surface finish.

Category 2. No body colour. The tile surface coating is applied in the manufacturing process.

Category 3. Body colour throughout. Colouring inorganic pigments are mixed in the concrete prior to the extrusion process.

Category 4. Body colour throughout. Coating, typically acrylic, is factory-applied. This eliminates colour variation and efflorescence.

Note: A wide range of fittings are available to match all roof tiles.

e) Definitions

For the purposes of this publication, the following definitions shall apply:

Abutment. An intersection on the roof surface and a part of the structure that rises above it.

Apex. The intersection of two or more roof slopes at the highest position on the roof.

Apron flashing. A flashing, the lower edge of which is dressed over the roof covering, and the upper edge of which is dressed up a vertical surface.

Bargeboard. A component fixed along the edges of a gable and covering the ends of the horizontal roof members.

Battens. Timber or steel members of small section fixed parallel to the line of the eaves, at right angles to the rafters, onto which tiles are fixed.

Bedding. The setting and pointing of tiles and fittings in mortar.

Bedding pieces. Small pieces of broken tile that are used to reinforce areas of bedding where excessive mortar shrinkage can occur.

Boards. Lengths of flat timber that are nailed to the rafters to form a soffit and act as a support for the underlay.

Cleat. A specially formed strip of corrosion-resistant material (eg. of the same material as the valley liner) that is used to hold the valley liner in place.

Coastal area. The area between the sea and a line 5km inland.

Concealed gutter. A pre-formed channel (manufactured from a suitable corrosion-resistant material) that is overlapped by tiles and shaped to form a watertight joint at abutments (in conjunction with cover flashings).

Counter battens. Timber members of small section fixed between the battens and the underlying structure, normally at right angles to the direction of the battens onto which the tiles are laid.

Cover flashing. A flashing that is used in conjunction with other roof components (such as side gutters and apron flashings) and that overlaps any vertical parts of such components.

Eaves. The overhanging lower edge of a roof slope.

Fascia board. A member, cut from sheet material or timber that is fixed to the rafter ends, the wall face or the wall plate immediately below the eaves.

Flashing. A strip of flexible impervious material that is used to exclude water from the junction between a roof covering and another part of the structure.

Gable. The part of the wall above the general level of the eaves at the end of a ridge roof or of a partially hipped roof.

Gutter. Any form of roof-water channel at eaves, verges and abutments.

Head lap. The distance by which one course of tiles overlaps the course immediately below it.

Hip. The sloping intersection of two inclined roof surfaces that meet at a reflex angle (greater than 180°).

Monoridge. The intersection of a single roof slope and a vertical masonry face at the highest part of the roof.

Mortar. A mixture of sharp plaster sand, cement and inorganic pigment (optional) used for bedding tiles, ridges and fittings.

Pitch. The angle of inclination to the horizontal of the rafters, or of the surface on which tiles are laid.

Rafter. A supported structural member, usually timber, establishing the slope of the roof to which the battens, counter battens, boards or underlay are fixed.

Ridge. The horizontal junction between two roof slopes at the apex.

Soffit closure. A closure manufactured from rigid materials, fitted to the underside of the roof over-hang at eaves and verges.

Tilting batten. A batten that is used at eaves to support the tiles in the correct plane relative to the roof surface.

Truss. A structural system of timber or metal members that supports the roof covering and forms part of the structure to support a ceiling.

Underlay. A flexible undertile membrane fitted between the roof support structure and the battens.

Valley. The sloping intersection of two inclined roof surfaces that meet at a re-entrant angle (less than 180°).

Valley liner or gutter. A strip of impervious material that is used to exclude water at the sloping intersection of two intersecting roof surfaces.

Verge. The edge of a roof surface at a gable.

Welt. The edge of the valley liner that is so shaped that the cleats can hook onto it.

Concrete Roof Tiles

Section 2 Technical Data

Section 2: Technical Data

	CONTENTS	PAGE
2.1	Structural data	30
2.2	Physical properties	31
2.3	Underlays	32
2.4	Below minimum pitch specification	35
2.5	Condensation and ventilation	37
2.6	Roof pitch, wind forces and fixing recommendations	39
2.7	Estimating	47
2.8	Tender specification and bill of quantities	51
2.9	General notes	55

2.1 Structural Data

Table 2: Tiling data

	Flat Double Roman, Bold Double Roman, Bold Roll, Double Pan, Marseilles Profiles		Flat Profile
	Pitch 17,5° to 25°	Pitch 26° and above	Pitch 26° and above
Tile head lap (minimum)	100mm	75mm	100mm
Batten centres (maximum)	320mm	345mm	320mm
Length of battens per m ² (average)	3,15m	2,99m	3,15m
Tiles per m ² (average)	10,42	9,66	10,8
Mass of tiles per m ² (average)	48kg	45kg	56kg

Table 3: Rafter and batten data

Nominal size of tiles	420mm x 330mm
Rafter centres (maximum)	760mm with 38 x 38mm battens 760-900mm with 38 x 50mm battens fixed flat 900-1000mm with 38 x 50mm battens fixed on edge
Note: Spacing of rafters beyond 760mm centres may only be increased with engineer-designed trusses using 38x50mm battens of the correct grade. All structural timber to comply with SANS 1783-2, 1783-4 and 10149	
Distance from top edge of first batten to outside edge of fascia board. Refer to Figure 1	335-340mm depending on manufacturer's requirements
Distance from top edge of first batten to outside of rafter where no fascia is used. Refer to Figure 2	305mm
Distance from top edge to top batten to rafter apex. Refer to Figure 3	25mm (or flat profile 25-50mm – refer to manufacturer)




Figure 1: Eaves batten position using fascia





Figure 2: Eaves batten position without fascia



Legend

- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 32 – Fascia
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 63 – Tilting dimension

Figure 3: Ridge batten position

2.2 Physical Properties

Table 4: Physical properties

Parameters	Results
Dimensional tolerances	Complies with SABS specifications
Transverse strength	Complies with SABS specifications (minimum average breaking load 4,0 N/mm width)
Impact strength (hail resistance)	Tiles can withstand an impact energy of 20 Joules (equivalent to a 45mm hail stone)
Permeability	Complies with SABS specifications
Thermal properties	Conductivity $k = \text{m.K}$ Thermal resistance $R = \text{m}^2\text{K/W}$
Frost	Unaffected by frost
Fire	Non flammable, non combustible
Conductivity (lightning)	Concrete roof tiles are poor electrical conductors
UV Radiation	Unaffected by UV radiation
Durability	Tile body: lifetime of building
TV Reception	Concrete roof tiles have virtually no effect on the television signal and permit the use of internal aerials in accordance with SANS 1061-1975

2.3. Underlays

In current building practice, the undertile membrane has become an integral part of any tiled roof. When properly laid, it will provide a highly effective barrier against the ingress of wind-driven rain and dust. The pressures exerted by wind forces will also be substantially reduced due to pressure equalisation, greatly reducing the risk of wind uplift.

The use of suitable undertile membrane which complies with the requirements of type E of SANS 952 – 1985 or holds an Agrément approval certificate, having a nominal thickness of 250 microns (0,25mm) is recommended at all pitches in all areas.

It is essential for roof pitches below 26° and above 45° and for all roof pitches in coastal and other exposed and windy areas.

Undertile membrane must be fixed, prior to battening, horizontally over the rafters with a minimum overlap of 150mm and secured to the centre of the rafters with the minimum number of non-corrodible clout nails. The vertical laps must be secured over a rafter with a minimum overlap of 150mm.

At closed eaves, the undertile membrane must extend over the tilting batten and fascia board to allow drainage of water into the gutter.

It should be suitably supported by a rigid board behind the fascia board to prevent it from sagging and forming a water trap.

Refer to Figure 4




Figure 4: Undertile membrane closed eaves




Figure 5: Undertile membrane open eaves

Legend

- 01 – Roof tile
- 08 – Storm clip
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 30 – Timber support
- 31 – Timber framing
- 32 – Fascia
- 37 – Eaves lining
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 48 – Gutter
- 60 – Masonry wall

At open eaves, the undertile membrane should extend at least 20mm over the beam-filling on the exterior wall. Refer to Figure 5

Over hips, a strip of undertile membrane 600mm wide should be laid overlapping the undertile membrane of the main roof. Refer to Figure 6

In valleys, a similar strip of 600mm wide undertile membrane should be used and tucked under the underlay of the main roof. Refer to Figure 7

To avoid any damage to the undertile membrane, roofs should not be left exposed to UV radiation for any length of time.

Exposed undertile membrane can be damaged by excessive UV, strong wind, heavy rain and traffic on the roof.

In exposed areas it is recommended that the eaves and verges are closed. The undertile membrane must therefore be extended to the full overhang of the roof. Refer to Figure 4

If undertile membrane is damaged it is repaired by lifting the battens for the full width of the underlay and over a distance of two rafters. The replacement undertile membrane must be tucked under the top layer by at least 150mm and brought over the bottom layer by 150mm and have a vertical overlap of 150mm on either side of the rafter. It should be secured to the top of the rafters with clout nails. Refer to Figures 8 and 9




Figure 6: Hip 600mm overlay strip




Figure 7: Valley 600mm underlay strip

Legend

- 21 – Truss
- 22 – Rafter
- 43 – Undertile membrane
- 45 – Underlay strip
- 46 – Overlay strip

In house designs where the ceiling boards or boarding are fixed to the top of the rafters, counter battens must be fixed on top of the ceiling boards directly above the rafters. The

underlay should then be laid horizontally over the counter battens resting on top of the ceiling boards. The battens are fixed to the counter battens at the required spacing.




Figure 8: Undertile membrane over pitched roof illustrating laps




Figure 9: Undertile membrane over boarded roof illustrating laps

2.4 Below Minimum Pitch Specification

Introduction

The success of the members of the Concrete Roof Tile Division of the CMA has been achieved over many years by matching the requirements of both specifiers and the roofing industry with a range of concrete roof tiles that have proven durability, strength and performance in use. Concrete Roof Tiles, when correctly installed and maintained in accordance with SABS and CMA specifications and the requirements of SANS 10062 (1) should perform satisfactorily for the expected service life of the product.

Minimum Pitch and Lap Specifications

As part of the manufacturer's specification, each roof tile design size has a minimum pitch which may be associated with a particular surface finish, rafter length, severity of exposure or headlap.

For further information related to the performance of particular tiles please refer to the manufacturer's technical literature or contact the CMA.

Below Pitch Specification

Application. In certain instances the specifier has sometimes little option but to construct a roof below the minimum recommended pitch of the roof covering. These situations may include, for example, an extension to an existing property where the pitch is pre-determined by an upper window and minimum headroom requirements or a requirement to match the existing roof covering/structure.

A roof designed below the recommended minimum roof pitch should have a functional weatherproof sub-roof system capable of collecting any rainwater ingress and discharging it from the building. This sub-roof system should meet the recommendations for strength, water resistance, nail tear resistance, water vapour resistance (where required) and durability as required by SANS 10400 (2).

Specification. Although roof tile manufacturers are unable to provide assurance of the performance of their roofing

products in this situation, and any decision to proceed is at the specifier's own risk, the following specification aims to limit the risk of water ingress and might be considered suitable for smaller roof areas, such as extensions to existing domestic properties. To achieve this, the "groundwork" beneath the tiles must be improved; in effect becoming an "inclined flat roof".

We would recommend that this specification is limited to a minimum pitch of 12.5° for interlocking concrete tiles.

The proposed work will be subject to the requirements of the National Building Regulations (SANS 10400). We would recommend approval is obtained in the first instance from the Local Building Control Department.

The Below Pitch Specification should include the following:

- Laying 15mm external quality plywood boarding, selected to comply with standard SANS 929 (3), over the rafters with joints supported by rafters or noggins between the rafters.
- Tape all plywood joints with 50mm wide strips of duct tape.
- Nail one layer of 1200mm wide roofing felt to SANS 92 (4) to the taped plywood. The number of joints should be minimised by using continuous lengths of felt from the roll, with each layer overlapping the layer below.
- Fully bond a second layer of roofing felt over the first layer using a torch-on bitumen and staggering all joints between the first and second layers.
- The felt is then overlaid with well fixed 38mm x 19mm timber counterbattens (to SANS 1783 (5)) at spacings to suit the rafters.
- Lay one layer of undertile membrane to SANS 952 (6) or Agrément approved over the counterbattens with a minimum horizontal lap of 200mm and a vertical lap of 200mm. This underlay must be allowed to sag between the battens and not be pulled tight.

■ Interlocking Tiles

Fix 38mm x 38mm (up to 760mm rafter centres) or 38mm x 50mm (760mm to 900mm rafter centres) tiling battens (to SANS1783) at maximum gauge necessary to provide a minimum 100mm headlap.

Battens to be preservative treated as per statutory requirements in accordance with SANS 10005 (7) in the prescribed areas.

The minimum fixing for all tiles is to nail every third course and the full roof overhang. See SANS 10062 for further details.

REFERENCES

- | | | |
|----|------------|--|
| 1. | SANS 10062 | Fixing of interlocking roofing tiles. |
| 2. | SANS 10400 | The Application of the National Building Regulations |
| 3. | SANS 929 | Plywood and Composite Board |
| 4. | SANS 92 | Bituminous roofing felt |
| 5. | SANS 1783 | Sawn softwood timber |
| 6. | SANS 952 | Polyolefin film for damp-proofing and waterproofing in buildings |
| 7. | SANS 10005 | The preservative treatment of timber |

2.5 Condensation and Ventilation

Condensation occurs when warm moisture-laden air meets a surface which has a temperature below the dewpoint of the ambient air.

At steep pitches and in areas where tiles can be laid on battens without underlay, condensation inside the roof is usually not troublesome. It is minimised by the natural air flow around the tiles and should it occur on the underside of the tiles, the water formed will normally run down onto the upper surface of the next row of tiles below without dripping inside the roof.

When the roof has an underlay, condensation occurs on the underside of the underlay. It should be prevented by the provision of adequate ventilation at eaves, ridges and gable walls where applicable.

a) Eaves to eaves ventilation

Research has shown that a variable, but significant, proportion of dwelling heat can accumulate in the roof space. It is therefore important to ensure that all entries from the dwelling to the roof space, for instance around access hatches and service pipes and wires, are tightly sealed. It should be noted that eaves to eaves roof ventilation may be insufficient for certain climatic conditions.

For example this ventilation only functions when there is external air movement directed at right angles to the eaves of the building. Consequently there is a danger of stagnant, warm, moist air being trapped in the apex of the roof. When no air movement occurs, such as on cold, frosty nights in winter, temperature levels drop dramatically, causing condensation to form on the underside of the underlay.




Figure 10: Eaves to eaves ventilation




Figure 11: Eaves to ridge ventilation

b) Eaves to ridge ventilation

The most effective way to eliminate any condensation problems is to supplement eaves to eaves ventilation with ridge ventilation. Refer to Figure 11

This method has the benefit of ensuring an efficient ventilation flow in all climatic conditions by convection when no external air movement is present.

To all pitched roofs, with or without underlay, ventilated ridge tiles bring an effective solution to condensation problems by allowing a constant air flow in the roof space, preventing heat build-up. Refer to Figure 14




Figure 12: Ventilated closed eaves




Figure 13: Open eaves with air brick




Figure 14: Ventilated ridge tile

Legend

- 01 – Roof tile
- 06 – Ventilated ridge
- 08 – Storm clip
- 11 – Mortar bed
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 30 – Timber support
- 32 – Fascia
- 37 – Eaves lining
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 48 – Gutter
- 62 – Air brick

2.6 Roof Pitch, Wind Forces and Fixing Recommendations

a) Roof pitch

The basic principle to be considered in roof design is that the roof pitch should be adequate to discharge rainwater in the shortest time possible.

An important factor which should be considered when choosing a pitch for the roof is the effect wind forces have on roofs.

These forces vary according to the speed and direction of the wind, the degree of exposure, the height and pitch of the roof. The uplift or suction created by wind forces is greater on lower roof pitches.

The minimum roof pitch and minimum head lap as specified in Table 2 must therefore not be reduced under any circumstances. It is preferable to raise the safety factor of the roof by adding a full course of tiles and increasing the tile head lap evenly on the rafter length.

While the tile head lap may be increased, on exposed sites, greater lap is not as effective as a steeper pitch.

In certain coastal areas where rain and wind conditions are known to be severe, it is good practice to increase the roof pitch by 5° above the minimum pitches in addition to providing adequate fixing methods. For roof pitches above 45° , and for vertical cladding, the roof tiles must be nailed and clipped.

b) Wind forces and fixing recommendations

To ensure the satisfactory performance of a roof, the following factors should be taken into consideration:

- Type of building
- Pitch of roof
- Terrain category
- Basic wind speed
- Height of roof from ground to ridge
- Length of the roof slope

There are three minimum fixing specifications, A, B and C, for concrete roof tiles which are suitable for all normal roofing situations.

Fixing Tables

The procedure for using these tables is as follows:

Select the building type

- Double pitch roof on single storey
- Double pitch roof on two storeys
- Double pitch roof on three storeys
- Monopitch roof

Select the appropriate roof pitch

- Determine the terrain category
- Determine the height from ground to ridge
- Determine the basic wind speed for the terrain from the map
- Read off specification A, B or C

In case of complex roof designs, exceptionally long rafter lengths (exceeding 8,0m) or buildings located in areas where extreme wind conditions prevail; more stringent fixing specifications may be required. For advice contact the manufacturer.

When considering the wind forces acting on the windward slope of pitched roofs, the pressure is dependent on the pitch. When the roof angle is less 30° , the windward slope can be subjected to severe suction or negative pressure. Roofs steeper than 35° generally




Figure 15: Wind forces on flat pitches




Figure 16: Wind forces on steep pitches

present sufficient obstruction to the wind for a positive pressure to be developed on their windward slopes. Even here, though, there is an area near the ridge where suction is developed.

The leeward slopes are always subject to suction, though this is not usually as strong as that produced near the windward edge. Refer to Figures 15 and 16

Under strong gusting wind conditions, the suction force on the roof tiles may be in excess of the mass of the tiles, thus requiring them to be securely fixed to prevent them from being lifted from the building. Wind tunnel tests have also shown the benefits provided by the roofing underlay in resisting upward wind loads.

No reliance should be placed on the shear or tensile strength of mortar to hold monoridge tiles and ridge tiles on steep or vertical hips, or at any place where there is a risk of differential movement. This means that mechanical fixing is necessary to prevent them from being dislodged.

Within the general roof area the tensile strength and pull-out resistance of nails become important. At lower pitches tile clips provide resistance to the applied lifting force more successfully than nails which, due to their closeness to the pivot line where the nib touches the batten, cannot resist the uplift force created at the tail. Refer to Figure 17. At steeper pitches it is important to prevent the tiles from being dislodged and from rattling under wind gusting.




Figure 17: Clip fixing / Nail fixing

Storm damage due to excessive wind gusting occurs in most instances at eaves, verges and under ridges.

It is therefore recommended that, in semi-exposed and exposed roof situations, the mechanical fixing in these particular areas of the roof be improved. Rake verge tiles should be used at gable ends to secure the verges.

Storm damage due to excessive wind gusting seldom occurs at hips and valleys and additional mechanical fixing other than specified is not necessary. At valleys it is more important to ensure the correct width for the valley liner and good installation to prevent rain water from overflow into the roof space.

c) Additional fixing

In severe or adverse wind load situation, special fixing specifications are required.

These situations are:

- complex roof designs in semi-exposed or exposed areas
- steep pitches, vertical tiling and monopitch roofs (shopping malls, schools, etc.)

The special fixing specifications may include:

- Use of serrated nails or screws instead of normal fixing nails.
- Double fixing (in addition to normal fixing) in the pan of the tile. Additional fixing holes in tiles and fittings to be drilled on site as required.


d) Exceptional rafter lengths

On very long rafter lengths the tile head lap must be increased as required, especially as the lower part of the roof sheds a large volume of rain water.

e) Terrain categories

Terrain category 1

Exposed open terrain with few or no obstructions and in which the average height of an object surrounding the structure is less than 1,5m in height. This category includes open sea coasts and flat, treeless plains with little vegetation other than grass.



Terrain category 2

Open terrain with well scattered obstructions having heights generally between 1,5m and 10m. This category includes most parklands and undeveloped sparsely built-up outskirts of towns and suburbs.



Terrain category 3

Terrain with numerous closely spaced obstructions the size of domestic houses. This category includes well-wooded areas and suburbs, town and industrial areas.




Terrain category 4

Terrain with numerous large, high, closely spaced obstructions. This category includes large city centres.



f) Regional basic design wind speed (as defined in SANS 10160-1989)

The values given here are based on a statistical analysis of data gathered by the Weather Bureau of the Department of Transport over many years at a number of stations throughout the Republic. To obtain wind speeds for intermediate locations, either use linear interpolation or use the higher value isopleth.



Where local wind speed records of sufficient duration and reliability are available to the designer of a building in a given locality, these may be used to determine the regional basic wind speed instead of the value derived from this map, provided that lower wind speeds are not adopted without the approval of the local authority.

In local areas where there is knowledge of the occurrence of high wind gusts and severe lifting forces (i.e. certain coastal areas, highveld storm areas, wind funnelling or other effects) interpolation must be done to the highest value.

g) Minimum fixing specifications

Fixing specification A (Unexposed roof situations)

Mechanically fix two courses of tiles at eaves and verges (or the full overhang, whichever is greater) and at ridges, and one adjacent full tile at valleys, hips and abutments. Cut tiles at valleys, hips and abutments to be secured by nailing or wiring, as required.

Roof pitches from 17,5° up to 26°

Undertile membrane mandatory.

Roof pitches from 26° up to 45°

Undertile membrane recommended.

Roof pitches from 45° up to 55°

Each tile to be nailed or clipped

Undertile membrane recommended

Roof pitches from 55° to 90°

Each tile to be nailed and clipped

Undertile membrane mandatory




Figure 18: Fixing requirements
– Specification A

Fixing specification B (Semi-exposed roof situations)

Mechanically fix a band of tiles (x) equal to a fifth of the number of courses on the rafter length at eaves and verges or the full overhang, whichever is the greater, and at ridges and abutments; and one adjacent full tile at hips and valleys, and every third tile on the rest of the roof. Cut tiles at hips, valleys and abutments to be secured by nailing or wiring as required.

Example: 15 courses on the rafter:

X = 3 courses

Soffits should be closed at eaves and verge overhangs.

Roof pitches from 17,5° up to 26°

Undertile membrane mandatory

Roof pitches from 26° up to 45°

Undertile membrane recommended

Roof pitches from 45° to 90°

Each tile to be nailed and clipped

Undertile membrane mandatory




Figure 19: Fixing requirements – Specification B

Fixing specification C (Exposed roof situations and roofs in coastal areas*)

Each tile fixed

Soffits must be closed at eaves and verge overhangs.

Roof pitches from 17,5° up to 45°

Each tile to be nailed or clipped

Undertile membrane mandatory

Roof pitches from 45° to 90°

Each tile to be nailed and clipped

Undertile membrane mandatory

* Generally, the area within 5km from the coast-line unless otherwise defined locally.




Figure 20: Fixing requirements –Specification C

Table 5: Minimum fixing recommendations for roofs on single storey buildings

17,5° ≤ Pitch < 22,5°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	3	B	B	B	B	C	C	C	C	C	C
	5	B	B	B	C	C	C	C	C	C	C
	10	B	C	C	C	C	C	C	C	C	C
2	3	A	A	A	A	B	B	B	C	C	C
	5	A	A	B	B	B	C	C	C	C	C
	10	B	C	C	C	C	C	C	C	C	C
3	3	A	A	A	A	A	A	B	B	B	B
	5	A	A	A	A	B	B	B	C	C	C
	10	A	B	B	B	B	C	C	C	C	C
4	3	A	A	A	A	A	A	A	A	A	B
	5	A	A	A	A	A	A	A	B	B	B
	10	A	A	A	A	A	B	B	B	B	C

22,5° ≤ Pitch < 26°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	3	B	B	B	B	B	C	C	C	C	C
	5	B	B	B	B	C	C	C	C	C	C
	10	B	B	C	C	C	C	C	C	C	C
2	3	A	A	A	A	B	B	B	B	C	C
	5	A	A	B	B	B	B	C	C	C	C
	10	B	B	C	C	C	C	C	C	C	C
3	3	A	A	A	A	A	B	B	B	B	B
	5	A	A	A	B	B	B	B	B	B	C
	10	A	B	B	B	B	B	C	C	C	C
4	3	A	A	A	A	A	A	A	A	A	B
	5	A	A	A	A	A	A	A	B	B	B
	10	A	A	A	A	B	B	B	B	B	B

26° ≤ Pitch < 30°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	3	B	B	B	B	B	C	C	C	C	C
	5	B	B	B	C	C	C	C	C	C	C
	10	B	C	C	C	C	C	C	C	C	C
2	3	A	A	A	A	B	B	B	B	C	C
	5	A	A	B	B	B	B	C	C	C	C
	10	B	B	C	C	C	C	C	C	C	C
3	3	A	A	A	A	A	B	B	B	B	B
	5	A	A	A	B	B	B	B	B	B	C
	10	A	B	B	B	B	B	C	C	C	C
4	3	A	A	A	A	A	A	A	A	A	B
	5	A	A	A	A	A	A	A	B	B	B
	10	A	A	A	A	B	B	B	B	B	B

30° ≤ Pitch < 35°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	3	B	B	B	B	C	C	C	C	C	C
	5	B	B	B	B	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
2	3	A	A	B	B	B	B	B	B	C	C
	5	B	B	B	B	B	C	C	C	C	C
	10	B	B	C	C	C	C	C	C	C	C
3	3	A	A	A	A	A	B	B	B	B	B
	5	A	A	A	B	B	B	B	B	C	C
	10	A	B	B	B	B	B	C	C	C	C
4	3	A	A	A	A	A	A	A	A	B	B
	5	A	A	A	A	A	A	B	B	B	B
	10	A	A	A	A	B	B	B	B	B	B

35° ≤ Pitch < 40°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	3	B	B	B	B	C	C	C	C	C	C
	5	B	B	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
2	3	A	A	B	B	B	B	B	C	C	C
	5	B	B	B	B	B	C	C	C	C	C
	10	B	C	C	C	C	C	C	C	C	C
3	3	A	A	A	A	B	B	B	B	B	C
	5	A	A	B	B	B	B	B	B	C	C
	10	B	B	B	B	B	C	C	C	C	C
4	3	A	A	A	A	A	A	A	A	B	B
	5	A	A	A	A	A	A	B	B	B	B
	10	A	A	A	B	B	B	B	B	B	C

40° ≤ Pitch < 45°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	3	B	B	C	C	C	C	C	C	C	C
	5	B	C	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
2	3	A	B	B	B	B	C	C	C	C	C
	5	B	B	B	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
3	3	A	A	A	A	B	B	B	B	C	C
	5	A	A	B	B	B	B	C	C	C	C
	10	B	B	B	B	C	C	C	C	C	C
4	3	A	A	A	A	A	A	A	B	B	B
	5	A	A	A	A	A	B	B	B	B	B
	10	A	A	A	B	B	B	C	C	C	C

A = Perimeter only

B = Perimeter and local roof area

C = Each tile fixed

h = Height from ground to ridge, m

w = Basic wind speed on terrain, m/s



Unshaded areas: Undertile membrane essential



Shaded areas: Undertile membrane recommended

Table 6: Minimum fixing recommendations for roofs on two storey buildings

17,5° ≤ Pitch < 22,5°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	B	C	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	B	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	A	A	B	B	B	B	B	C	C	C
	10	B	B	B	C	C	C	C	C	C	C
	15	B	C	C	C	C	C	C	C	C	C
4	5	A	A	A	A	A	B	B	B	B	B
	10	A	A	B	B	B	B	B	C	C	C
	15	B	B	B	B	B	C	C	C	C	C

22,5° ≤ Pitch < 26°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	B	B	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	B	B	C	C	C	C	C	C
	10	B	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	A	A	B	B	B	B	B	C	C	C
	10	B	B	B	B	B	C	C	C	C	C
	15	B	B	C	C	C	C	C	C	C	C
4	5	A	A	A	A	A	A	B	B	B	B
	10	A	A	A	B	B	B	B	B	C	C
	15	A	B	B	B	B	B	C	C	C	C

26° ≤ Pitch < 30°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	B	B	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	B	B	B	C	C	C	C	C
	10	B	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	A	A	A	B	B	B	B	B	C	C
	10	A	B	B	B	B	C	C	C	C	C
	15	B	B	C	C	C	C	C	C	C	C
4	5	A	A	A	A	A	A	B	B	B	B
	10	A	A	A	A	B	B	B	B	B	C
	15	A	A	B	B	B	B	C	C	C	C

30° ≤ Pitch < 35°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	B	B	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	B	B	B	C	C	C	C	C
	10	B	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	A	A	A	B	B	B	B	C	C	C
	10	A	B	B	B	B	C	C	C	C	C
	15	B	B	C	C	C	C	C	C	C	C
4	5	A	A	A	A	A	A	B	B	B	B
	10	A	A	A	A	B	B	B	B	B	C
	15	A	A	B	B	B	B	C	C	C	C

35° ≤ Pitch < 40°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	B	B	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	B	B	C	C	C	C	C	C
	10	B	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	A	A	B	B	B	B	B	C	C	C
	10	B	B	B	B	C	C	C	C	C	C
	15	B	B	C	C	C	C	C	C	C	C
4	5	A	A	A	A	A	A	B	B	B	B
	10	A	A	B	B	B	B	B	B	C	C
	15	A	B	B	B	B	C	C	C	C	C

40° ≤ Pitch < 45°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	B	C	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	B	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	A	A	B	B	B	B	C	C	C	C
	10	B	B	B	B	C	C	C	C	C	C
	15	B	C	C	C	C	C	C	C	C	C
4	5	A	A	A	A	A	A	B	B	B	B
	10	A	A	A	B	B	B	B	C	C	C
	15	A	B	B	B	B	C	C	C	C	C

A = Perimeter only

B = Perimeter and local roof area

C = Each tile fixed

h = Height from ground to ridge, m

w = Basic wind speed on terrain, m/s



Unshaded areas: Undertile membrane essential



Shaded areas: Undertile membrane recommended

Table 7: Minimum fixing recommendations for roofs on three storey buildings

17,5° ≤ Pitch < 22,5°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
2	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
3	10	B	B	B	B	C	C	C	C	C	C
	15	B	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
4	10	A	A	B	B	B	B	B	C	C	C
	15	B	B	B	B	B	C	C	C	C	C
	20	B	B	B	C	C	C	C	C	C	C

22,5° ≤ Pitch < 26°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
2	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
3	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
4	10	A	A	A	B	B	B	C	C	C	C
	15	A	B	B	B	C	C	C	C	C	C
	20	B	B	C	C	C	C	C	C	C	C

26° ≤ Pitch < 30°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
2	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
3	10	B	B	B	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
4	10	A	A	A	B	B	B	C	C	C	C
	15	A	B	B	B	C	C	C	C	C	C
	20	B	B	C	C	C	C	C	C	C	C

30° ≤ Pitch < 35°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
2	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
3	10	B	B	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
4	10	A	A	B	B	B	C	C	C	C	C
	15	B	B	B	C	C	C	C	C	C	C
	20	B	C	C	C	C	C	C	C	C	C

35° ≤ Pitch < 40°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
2	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
3	10	B	B	B	B	C	C	C	C	C	C
	15	B	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
4	10	A	A	A	B	B	B	B	C	C	C
	15	A	B	B	B	B	B	C	C	C	C
	20	B	B	B	C	C	C	C	C	C	C

40° ≤ Pitch < 45°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
2	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
3	10	B	B	B	B	C	C	C	C	C	C
	15	B	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
4	10	A	A	A	B	B	B	B	C	C	C
	15	A	B	B	B	B	C	C	C	C	C
	20	B	B	B	C	C	C	C	C	C	C

A = Perimeter only

B = Perimeter and local roof area

C = Each tile fixed

h = Height from ground to ridge, m

w = Basic wind speed on terrain, m/s



Unshaded areas: Undertile membrane essential



Shaded areas: Undertile membrane recommended

Table 8: Minimum fixing recommendations for monopitch roofs

17,5° ≤ Pitch < 22,5°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	C	C	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	B	B	B	B	B	C	C	C	C	C
	10	B	B	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
4	5	A	A	A	A	A	B	B	B	B	C
	10	A	B	B	B	B	B	C	C	C	C
	15	B	B	B	C	C	C	C	C	C	C

22,5° ≤ Pitch < 26°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	C	C	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	B	B	B	B	C	C	C	C	C	C
	10	B	B	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
4	5	A	A	A	B	B	B	B	B	C	C
	10	A	B	B	B	B	B	C	C	C	C
	15	B	B	B	B	C	C	C	C	C	C

26° ≤ Pitch < 30°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	C	C	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	B	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	B	B	B	B	C	C	C	C	C	C
	10	B	B	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
4	5	A	A	A	B	B	B	B	B	C	C
	10	A	B	B	B	B	C	C	C	C	C
	15	B	B	B	C	C	C	C	C	C	C

30° ≤ Pitch < 35°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	5	C	C	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
2	5	B	C	C	C	C	C	C	C	C	C
	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
3	5	B	B	B	B	C	C	C	C	C	C
	10	B	B	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
4	5	A	A	A	B	B	B	B	B	C	C
	10	A	B	B	B	B	C	C	C	C	C
	15	B	B	B	C	C	C	C	C	C	C

35° ≤ Pitch < 40°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
2	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
3	10	B	B	B	B	C	C	C	C	C	C
	15	B	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
4	10	A	A	A	B	B	B	B	C	C	C
	15	A	B	B	B	B	B	C	C	C	C
	20	B	B	B	C	C	C	C	C	C	C

40° ≤ Pitch < 45°

Terrain Category	h \ w	38	40	42	44	46	48	50	52	54	56
1	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
2	10	C	C	C	C	C	C	C	C	C	C
	15	C	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
3	10	B	B	B	B	C	C	C	C	C	C
	15	B	C	C	C	C	C	C	C	C	C
	20	C	C	C	C	C	C	C	C	C	C
4	10	A	A	A	B	B	B	B	C	C	C
	15	A	B	B	B	B	C	C	C	C	C
	20	B	B	B	C	C	C	C	C	C	C

A = Perimeter only

B = Perimeter and local roof area

C = Each tile fixed

h = Height from ground to ridge, m

w = Basic wind speed on terrain, m/s



Unshaded areas: Undertile membrane essential



Shaded areas: Undertile membrane recommended

2.7 Estimating

This guide has been compiled to estimate concrete roof tile quantities. To use this guide one should acquaint oneself with the roofing terminology used in the concrete roof tile industry. Reference should also be made to the definitions of building terms and of roof forms which can be found in Section 1.

Eaves length. The total length of the roof at eaves, including verge overhangs.

Roof span. The projected span of the roof on the plan, including eaves overhangs.

Rafter span. The projected span of a rafter length, equal to half the roof span, for a symmetrical double pitched roof.

Rafter length. The distance measured on top of the rafter, between the rafter apex and the end of the rafter at eaves, or the outside edge of the fascia board, if any.

Roof plan area. The flat surface area on the plan calculated from the roof line.

Roof area to slope. The actual area to be tiled.

Roof pitch. The angle between the rafter and the horizontal. Rafter pitch = roof pitch.

Roof constant multipliers. Constant factors used in roof calculations. Refer to Table 9

The head lap. The distance by which the tiles overlap one another.

Roofline on the plan. The projected line of the roof perimeter on the plan, including verge eaves and gutter overhang.

Gutter overhang. The distance by which the tiles overhang the fascia board over the gutter. For estimating purposes (standard 100mm gutter) this distance is assumed at: 50mm on the plan, 60mm on the slope.

Tile pitch. The angle between the tile when laid on the roof and the horizontal. The tile pitch is generally 5° lower than the roof pitch.

Batten centres. The distance by which the battens are spaced, measured from top of batten to top of batten or from centre to centre.

Ridge length. The horizontal length of the roof apex.

Hip and Valley length. The length of a hip or valley measured from eaves to apex.

Note: the length of the hip or valley cannot be measured off the plan and must always be calculated.




Figure 22: Roof terminology




Figure 23: Roof plan




Figure 24: Tile head lap

Calculating roof tile quantities

The two methods of calculating roof tile quantities are:

- a) Eaves length/rafter length method
- b) Roof area method

To calculate the number of tiles required it is necessary to have working drawings showing lengths of eaves, rafters and roof pitch. Roofs having the same eaves overhang and rafter length and roof pitch will have the same roof area regardless of whether the roof has hipped or gabled ends. If rafter lengths cannot be taken off the drawings they can be calculated as follows:

To calculate the rafter length at a given pitch, multiply the rafter span (including the eaves overhang) by the appropriate rafter constant. Refer to Table 9

Rafter length = rafter span x rafter constant.

To calculate the valley or hip length multiply the rafter span by the appropriate valley/hip constant. Valley/hip rafter length = rafter span x valley/hip constant.




Figure 25: Calculating length of rafter, valley or hip

- a) Eaves length/rafter length method

This is an accurate method and is recommended when calculating quantities of tiles required.

- Using Table 10 Column 4 read off the number of tiles required along the length of the eaves. Round up to the nearest full tile.

- Using Table 10 read off the number of courses required on the rafter length at the relevant tile head lap. Round up to the nearest full tile.
- Multiply the number of tiles along the eaves by the number of courses on the rafter length for each roof area. Add the totals together.
- Add 2% of total for wastage.

- b) Roof area method

Reduce the roof plan to basic areas.

- Calculate each roof area on plan by multiplying eaves length of each roof area by the roof span.
- Total area of roof to be tiled = sum of various areas on plan x constant for the appropriate roof pitch. Refer to Table 9
- If the roof has different pitches for the various areas, then each area should be calculated separately.
- As this roof area method is only approximate add 5% for wastage
- Valleys and hips: extra tiles for cutting.
Length of hips and valleys = number of hips/valleys x rafter span x hip/valley constant. Refer to Table 9
Extra tiles for hips = length of hips x 3.
Extra tiles for valleys = length of valleys x 4.
- Add 2% for wastage. Round up to nearest 10.

- Ridge tile quantity for ridges and hips
Total ridge/hip tiles required = length of ridge/hip x number of ridge/hip tiles/m.

Refer to manufacturer if in doubt

Add one ridge tile per length of ridge. Add one ridge tile per hip for mitring at ridge/hip junction.

- Add 5% for wastage.
- Verge. For each verge allow one rake verge tile for each course of tiling and one extra verge tile for mitring at the apex.
- Add 5% for wastage.

Table 9: Roof rafter constant multipliers


Roof pitch	Rafter 	Valley/Hip For calculations in between use the preceding higher constant.			Rise 
		 90° Standard	 120°	 150°	
17,5°	1,049	1,450	1,197	1,082	0,315
18°	1,051	1,451	1,200	1,085	0,325
19°	1,058	1,456	1,205	1,091	0,344
20°	1,064	1,460	1,211	1,097	0,364
21°	1,071	1,465	1,217	1,104	0,384
22°	1,079	1,471	1,224	1,111	0,404
22,5°	1,082	1,473	1,227	1,115	0,414
23°	1,086	1,476	1,230	1,118	0,424
24°	1,095	1,482	1,238	1,127	0,445
25°	1,103	1,488	1,246	1,135	0,466
26°	1,113	1,496	1,254	1,144	0,488
27°	1,122	1,503	1,263	1,154	0,510
27,5°	1,127	1,506	1,267	1,159	0,521
28°	1,133	1,511	1,272	1,164	0,532
29°	1,143	1,519	1,281	1,174	0,554
30°	1,155	1,528	1,291	1,185	0,577
31°	1,167	1,537	1,302	1,197	0,601
32°	1,179	1,546	1,313	1,209	0,625
32,5°	1,186	1,551	1,319	1,215	0,637
33°	1,192	1,556	1,325	1,220	0,649
34°	1,206	1,567	1,338	1,236	0,675
35°	1,221	1,578	1,351	1,294	0,70
36°	1,236	1,590	1,365	1,265	0,727
37°	1,252	1,602	1,379	1,281	0,754
37,5°	1,260	1,609	1,387	1,288	0,767
38°	1,269	1,616	1,394	1,297	0,781
39°	1,287	1,630	1,411	1,314	0,810
40°	1,305	1,644	1,428	1,332	0,839
41°	1,325	1,660	1,445	1,351	0,869
42°	1,346	1,677	1,464	1,372	0,900
42,5°	1,356	1,685	1,474	1,382	0,916
43°	1,367	1,695	1,484	1,393	0,933
44°	1,390	1,712	1,506	1,416	0,966
45°	1,414	1,732	1,528	1,439	1,000
46°	1,440	1,753	1,552	1,464	1,036
47°	1,466	1,775	1,567	1,490	1,072
47,5°	1,480	1,786	1,589	1,504	1,091
48°	1,494	1,798	1,603	1,518	1,111
49°	1,524	1,823	1,630	1,547	1,150
50°	1,556	1,850	1,660	1,579	1,192
51°	1,589	1,877	1,69	1,611	1,235
52°	1,624	1,907	1,724	1,646	1,280
52,5°	1,643	1,923	1,741	1,664	1,303
53°	1,662	1,940	1,759	1,683	1,327
54°	1,701	1,973	1,797	1,722	1,376
55°	1,743	1,009	1,837	1,764	1,428
56°	1,788	2,049	1,880	1,808	1,483
57°	1,836	2,091	1,925	1,855	1,540
57,5°	1,861	2,113	1,949	1,880	1,570
58°	1,887	2,136	1,973	1,906	1,600
59°	1,942	2,184	2,026	1,960	1,664
60°	2,000	2,236	2,082	2,018	1,732

Table 10: Tile cover – rafter / eaves

Number of tiles Nominal size of tiles 420 x 330mm	Rafter		Eaves
	Roof pitch		Nominal cover on eaves length m
	17,5° – 25° 100mm head lap 320mm batten centres m	26° and above 75mm head lap 345mm batten centres m	
1	0,360	0,360	0,332
2	0,680	0,705	0,633
3	1,000	1,050	0,934
4	1,320	1,395	1,235
5	1,640	1,740	1,536
6	1,960	2,085	1,837
7	2,280	2,430	2,138
8	2,600	2,775	2,439
9	2,920	3,120	2,740
10	3,240	3,465	3,041
11	3,560	3,810	3,342
12	3,880	4,155	3,643
13	4,200	4,500	3,944
14	4,520	4,845	4,245
15	4,840	5,190	4,546
16	5,160	5,535	4,847
17	5,480	5,880	5,148
18	5,800	6,225	5,449
19	6,120	6,570	5,750
20	6,440	6,915	6,051
21	6,760	7,260	6,352
22	7,080	7,605	6,653
23	7,400	7,950	6,954
24	7,720	8,295	7,255
25	8,040	8,640	7,556
26	8,360	8,985	7,857
27	8,680	9,330	8,158
28	9,000	9,675	8,459
29	9,320	10,020	8,760
30	9,640	10,365	9,061
31	9,960	10,710	9,362
32	10,280	11,055	9,663
33	10,600	11,400	9,964
34	10,920	11,745	10,265
35	11,240	12,090	10,566
36	11,560	12,435	10,867
37	11,880	12,780	11,168
38	12,200	13,125	11,469
39	12,520	13,470	11,770
40	12,840	13,815	12,071

2.8 Tender Specification and Bill of Quantities

a) Preamble – roof measuring

Standard system for roof measuring of concrete roof tiles.

General

Roof covering is measured nett and subject to remeasurement on completion of work. Wastage and breakage must always be added.

Tiling

Roof tiling with concrete roof tiles shall be given in square metres and must be separated into three categories.

- a) Flat slope – Not exceeding 25° from the horizontal
- b) Steep slope – From 26° to 55°
- c) Vertical – Exceeding 55°

Reference must be made in the bill of quantities to the height of the building, the number of storeys, the roof pitch and the batten centres (tile head lap). For roof pitches from 17,5° to 25° tiles must be laid with a minimum head lap of 100mm (maximum batten centres 320mm) with underlay mandatory. For roof pitches from 26° upwards tiles must be laid with a minimum head lap of 75mm (maximum batten centres 345mm).

Note: For flat profile tiles contact the manufacturer for minimum roof pitch, overlaps and batten centres.

Mechanical fixing of tiles shall be done strictly in accordance with the manufacturer's recommendations.

Coverings to dormers, turrets and the like shall be given separately. No deductions shall be made for openings, vents etc not exceeding 1m².

Raking and Cutting

Raking, cutting and waste at abutments, parapet walls, verges, skew eaves etc where not otherwise provided for shall be given in linear metres. Flashing material measured elsewhere.

Valleys

Close-cut and open-cut valleys shall be given in linear metres and the description shall include cutting of tiles and waste to both

sides. Wiring of cut tiles, as in the case of an open valley, shall be included in the description. Valley liner measured elsewhere.

Hips

Close-cut and mitred hips shall be given in linear metres. The description shall include cutting of tiles and waste to both sides, hip tiles, pigment bedding and pointing. Sand, cement and DPC to be provided by the main contractor, unless specified otherwise in the Bill of Quantities.

Ridges

Ridges shall be given in linear metres. The description shall include ridge tiles, (pigment bedding and pointing. Sand, cement and DPC to be provided by the main contractor, unless specified otherwise in the Bill of Quantities.

Verges

Verge installations formed with verge tiles shall be given in linear meters. The description shall include verge tiles, pigment bedding and pointing. Sand, cement and DPC to be provided by the main contractor, unless specified otherwise in the Bill of Quantities.

Purpose-made Tiles

Purpose made tiles to ends, ridges and verge tiles, ventilated ridge tiles etc. shall be given in number. The description shall include all fixing materials.

b) Preamble – roof covering

Standard system for fixing of concrete roof tiles

General

The following recommendations on installation shall be regarded as normal practice. Under certain circumstances material specifications may vary to suit local conditions of use.

Undertile Membrane

Prior to battening, an SABS or Agrément approved undertile membrane shall be laid horizontally over the rafters, with minimum overlaps of 150mm and secured with clout nails to the rafter centres.

The undertile membrane must allow drainage

of water and should extend over the tilting batten or fascia board into the gutter. Water traps behind the fascia board must be avoided. Alternatively, in open eaves, the undertile membrane should extend approximately 20mm over the beam-filling on the exterior wall.

A strip of undertile membrane not less than 600mm wide shall be laid over hips overlapping the undertile membrane of the main roof. At valleys a similar strip not less than 600mm wide shall be laid under the undertile membrane of the main roof.

Battens

All timber used for battening shall be graded SA pine complying with SANS 653-1980 Standard specifications for softwood brandering and battens.

The minimum batten sizes are:

- 38 x 38mm for rafter centres up to 760mm
- 38 x 50mm fixed flat for rafter centres from 760mm to 900mm
- 38 x 50mm fixed on edge for rafter centres from 900mm to 1 000mm
- The rafter centres can only be increased above 760mm with engineer designed trusses. All structural timber to comply with SANS 1783-4: 2004.

Battens shall be of sufficient length to be supported at each end and intermediately by a total of at least three rafters, trusses or walls. Counterbattens must be installed at valleys and if necessary, at hips to support the cut ends of the battens.

The verge counterbatten shall in all instances be 38 x 50mm fitted on edge to the ends of the battens at the eave ends.

At vertical hips and at pitches above 45° additional battens must be fixed on top of the hip rafter to form a live tree of sufficient height to permit mechanical fixing of the hip tiles.

At the ridge the top batten must be placed at a distance not exceeding 25mm from the rafter apex to ensure sufficient overlap of the ridge tiles over the top course of tiling. For slate tiles refer to the manufacturer.

The first batten at the eaves must be so positioned as to allow sufficient overhang of

the tiles over the fascia board or tilting batten to ensure that water discharges into the centre of the gutter.

Battening on boarded roofs with underlay should be supported by counterbattens to increase ventilation under the tiles and to allow free drainage of any water that may reach the undertile membrane.

Minimum head laps of 100mm must be maintained at roof pitches from 17,5° up to 26° and minimum head laps of 75mm at roof pitches from 26° upwards. Head laps can be increased to suit the rafter length in order to ensure that the last course of tiles under the ridge is in all instances a full tile.

Concrete Roof Tiles

Large interlocking concrete roof tiles of nominal size 420x330mm shall comply with the requirements of SANS 542-2004 and shall be of profile, colour and finish as described agreed between the specifier and the supplier.

Tiling

All tiling must be fixed in accordance with SANS 10062-2003 and comply with the manufacturer's recommendations. All roof overhangs must be mechanically fixed with non-corrodible clout nails or clips and the main body of the roof must be fixed in accordance with the manufacturer's specification applicable to locality and roof pitch. Nails or clips must penetrate battens to a minimum depth of 25mm.

Tiles (except flat tiles which are laid broken bond) are to be laid in straight bond with the vertical joints forming a straight line up the slope of the roof.

At all abutments where tiling meets walls or chimneys, and adequate flashing material must be used to weather proof the junction. All tiling must be cut close to the abutment.

Verges

Unless otherwise specified, verges shall be formed with purpose made verge tiles of similar colour and finish to those of the main roof tiles and must be fixed strictly in accordance with the manufacturer's recommendations.

Ridges

Ridges shall be covered with ridge tiles of similar colour and finish to those of the main tiles and shall be edge-bedded onto the last course of tiles in tinted 3:1 sand/cement mortar, strictly in accordance with the manufacturer's recommendations. All ridge tiles shall overlap the last course of tiling by a minimum of 75mm and the exposed mortar must be neatly pointed.

A strip of approved DPC sheeting 150mm wide should be placed lengthwise under the ridge tiles, overlapping the top course of tiling on each side by 25mm. Lapped ends must be supported underneath and the overlap should not be less than 150mm.

The end ridge tiles at gable ends should be solid bedded with mortar inset with pieces of tiles and neatly pointed at fair ends.

All ridge tiles shall be neatly cut and mitred at intersections with hips, intersecting ridges etc.

Monoridges are to be formed with purpose made monoridge tiles edge-bedded onto the top course of tiling as described for ridge tiles strictly in accordance with the manufacturer's recommendations.

Hips

Hips shall be covered with ridge tiles/hip tiles of similar colour and finish to those of the main roof tiles. The tiles should be cut closely to the rake of the hip, and the hip tiles shall be edge-bedded onto the tiles as described for ridge tiles.

The first hip tile should be shaped at the foot to the line of tiling at the eaves and the fair end filled with mortar inset with pieces of tile and neatly pointed. Alternatively hip starters should be used.

For vertical hips and at steep pitches above 45°, hip irons should be used and fixed to the hip tree with two screws or nails to support the first hip tile.

All other hip tiles must be nailed to the hip tree and bedded as detailed for hips and ridges.

Valleys

A non-corrodible valley flashing, at least 300mm wide, preferably with a preformed centre gutter, must be installed on the roof before tiling.

For open valleys the adjacent tiling must be neatly cut on both sides to form an open channel of at least 100mm wide. The cut tiles must be well fixed to the battens.

For closed valleys the adjacent tiles must be neatly cut on both sides to form a close fit and a straight line. The tiles must be holed and secured by nailing. If the cut tiles are very small and cannot be nailed they must be secured to the battens by means of bailing wire.

Mortar

All bedding and pointing mortar should consist of three parts sharp sand (plaster sand) and one part ordinary Portland cement suitably tinted with inorganic pigment to blend in with the tiling.

Bedding and pointing should be done in one operation and struck off at right angles to the roof plane to give a smooth finish. All ridges to be soaked in water before bedding to achieve improved bonding to mortar.

Table 11: Typical tender specifications for concrete roof tiles

Item No	Roof coverings	Quantity	Rate		Amount	
			R	c	R	c
	Refer to Preamble – roof covering Concrete roof tiles (state name of manufacturer and profile) through colour interlocking roof tiles, size 420 x 330mm, manufactured in accordance with SANS 542, of approved colour with matching fittings and accessories All tiling to be done in accordance with SANS 10062 and to comply with the manufacturer's recommendations. Tiling at 25° pitch with minimum head lap of 100mm and maximum batten centres of 320mm to single storey. All perimeter tiles must be mechanically fixed and the main body of the roof must be fixed in accordance with the manufacturer's recommendations applicable to the locality and roof pitch.					
1	Tiling to be (state name and profile) tiles laid straight bond to steep slope of 25°, fixed to battens at 320mm batten centres (maximum) (battens and underlay elsewhere measured) *Note: Broken bond for flat tiles	m ²				
2	Tiling to be (state name and profile) tiles laid straight bond to flat slope of 35°, fixed to battens at 345mm batten centres (maximum) (battens and underlay elsewhere measured) *Note: Broken bond for flat tiles	m ²				
3	Verges to be formed with VERGE TILES fixed in accordance with the manufacturer's recommendations	m ²				
4	Extra over verge tiling to form mitred intersection of ridge and two verge tiles	No				
5	Ridges to be covered with RIDGE TILES edge-bedded and pointed in tinted 3:1 sand/cement mortar over DPC 150mm wide	m				
6	Extra over ridge tiles for solid bedding and pointing of fair ends at gables	No				
7	Extra over ridge tiles to form mitred intersection of two ridges	No				
8	Monoridge to be covered with MONORIDGE TILES edge-bedded and pointed in 3:1 tinted sand/cement mortar over DPC 150mm wide	m				
9	Hips to be covered with RIDGE / HIP TILES edge-bedded and pointed in 3:1 tinted sand/cement mortar, over DPC 150mm wide, including cutting and waste to both sides	m				
10	Extra over hip tiles to install HIP STARTER	No				
11	Extra over hip tiles for shaping first ridge tiles at eaves, solid bedding and pointing of fair ends	No				
12	Extra over hip tiles to form mitred intersection of ridge and two hips	No				
13	Extra over hip tiles to form mitred intersection of four hips	No				
14	Close Cut Valley with adjacent tiles neatly machine cut on both sides to form a neat butt joint over the valley centre. Valley liner measured elsewhere	m				
15	Open Cut Valley with adjacent tiles carborundrum cut on both sides to form an open channel of at least 100mm. Valley liner measured elsewhere	m				
16	Raking, Cutting and Waste at abutments, parapets and verges	m				
17	Ventilated Ridge Terminals	No				
Total to Summary			R			

2.9 General Notes

Properly erected concrete roof tiles do not require any maintenance work or surface treatment to improve their durability or functional properties.

For aesthetic reasons however, it may become necessary to carry out maintenance work where roofs have become unsightly due to a number of factors:

a) Efflorescence

Efflorescence often referred to as “lime bloom”, is a natural phenomenon found in cementitious products such as concrete roof tiles. The cause lies in the chemical composition of the cement. When water added to cement a series of chemical reactions take place resulting in the setting and hardening. One product of these reactions “lime” in the form of calcium hydroxide which is slightly soluble in water and under certain conditions can migrate via capillaries in the concrete tile to the surface. There it reacts with the carbon dioxide from the atmosphere forming a white powder deposit of calcium carbonate crystals which is referred to as efflorescence.

Whilst the white deposit may appear unsightly, it is a temporary effect and should not be treated. With time and the natural process of weathering it will disappear restoring the true colour of the tile. This process can take three or four normal rainy seasons. This condition is purely superficial and does not affect the durability, the strength or the original colour of the tile.

At present there is no viable method during the production process of preventing efflorescence.

b) Fungal growth on roofs

Small deposits of fungal lichen or moss on a fairly new roof can be removed by using water and a hard bristle brush.

Where lichen has been prevalent for a number of years. It should be treated with approximately 2% copper sulphate solution to kill the growth. The roof should then be washed with a high-pressure water spray and a hard bristle brush.

If the roof cannot be restored to a uniform colour, it may require repainting. This can be carried out by using an approved pure acrylic paint which can be applied either by brush, roller or with spraying equipment.

c) Painting of tiled roofs

Where it is required to change the colour of the roof for aesthetic reasons, the roof should first be thoroughly cleaned. All dirt and dust should be washed down with water before a coat of approved pure acrylic paint is applied.

d) Health and safety instruction (Silicosis warning)

Many building products such as roof tiles are manufactured using natural raw materials. These raw materials contain a proportion of crystalline silica.

Powered mechanical processing such as cutting or drilling of the products will release some quantities of respirable silica dust.

Where exposure to this dust is high or prolonged over time, it can lead to lung disease (silicosis) and an increased risk of lung cancer.

The following control measures are required:

- An approved P3/FFP3 particulate respirator must be used during all cutting and drilling process.
- In addition, engineering controls such as wet cutting or dust extraction devices should be applied.

Concrete Roof Tiles

Section 3 Tiling Procedure

Section 3: Tiling Procedure

	CONTENTS	PAGE
3.1	Inspection before tiling	60
3.2	Setting out for tiling	61
3.3	Loading of the tiles on to the roof	61
3.4	Laying of tiles	62
3.5	Eaves	63
3.6	Valleys	64
3.7	Ridges	66
3.8	Hips	68
3.9	Verges	69
3.10	Abutments and flashings	71
3.11	Inspection after tiling	75

3.1 Inspection before Tiling

To ensure that a high standard of roof construction is achieved, it is essential that the timber structure is sound. It is therefore important that the following pre-tiling inspection be completed:

- Batten spacing must confirm with the manufacturer's specification and recommendations.
- Roof trusses are properly spaced, secured and adequately braced. Refer to section 5: Timber roof construction
- Undertile membrane is properly installed
- Hip and valley underlay/overlay strips are installed
- Trusses and battens must be true and level
- Battens have been fixed at valleys to support the valley flashing
- 38 x 50mm verge counterbattens have been installed.
- An additional batten has been fixed on top of the hip rafter to form a hip tree for fixing of hip tiles at roof pitches above 45°.

- The position of the first batten must be accurately established to ensure the correct overhang of the roof tiles into the gutter. Refer to Figures 26 and 27.
- The top batten must be positioned not more than 25mm from the rafter apex to ensure sufficient overlap of the ridge tile over the top course of tiling. Refer to Figure 28.
For flat tiles this dimension varies from 25-50mm – refer to manufacturer.
- Fascias, gutters and valley gutters have been installed.
- Parapet walls or any walls extending above the roof have been completed (including plastering and painting.)
- Abutment flashings have been installed. Refer to Figures 62-66.
- Beam fillings has been completed.

Note:

Ensure that all other trades are completed before tiling commences.




Figure 26: Eaves batten position with fascia




Figure 28: Top batten to apex distance




Figure 27: Eaves batten position without fascia

Legend

- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 32 – Fascia
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 63 – Tilting dimension

3.2 Setting out for Tiling

Set out one course of tiles from right to left along the eaves and along the ridge in order to achieve an equal overhang at both verges. By slightly adjusting the verge overhang and using the tolerance in the side interlock of the tile, the linear coverage of the roof can be achieved with full tiles. Refer to Figure 29

Where this is not possible, for instance between two parapet walls, cut tiles might have to be used at each end. Cut tiles should be on a size that can be securely fixed.

Chalk lines are then struck from eaves to ridge at three-tile intervals to guide tiling. Refer to Figure 31

Note: When setting out battens, the batten centres should be established from top batten to the eaves batten. This will ensure that the top course of tiles at the ridge as well as the bottom course at the eaves will always be made up of full tiles.

3.3 Loading of the Tiles on to the Roof

Care must be taken to avoid any damage to the undertile membrane during the loading of the roof tiles. The roof should be loaded evenly on either side from top to bottom by

placing stacks of six tiles between every second batten on top of the rafters. Refer to Figure 30




Figure 29: Setting out of tiles at ridges and eaves




Figure 30: Loading diagram

Legend

- 01 – Roof tile
- 15 – Tile stack
- 16 – Batten
- 17 – Tilting batten
- 19 – Verge counter batten
- 21 – Truss
- 60 – Masonry wall

3.4 Laying of Tiles

On completion of the setting out, the tiling work can proceed. Ensure that the first course of tiles at the eaves overhang passes the fascia board by an amount sufficient to ensure that water discharges freely into the centre of the gutter (min 50mm).

For positive location of the tiles, ensure that the tiles are fully supported by the battens on the batten bearers, and that the lugs of the tile butt-up squarely against the top edge of the battens. This will ensure that the tiles are in straight courses horizontally and vertically.

Standard interlocking tiles should be laid from right to left, from eaves to ridge, taking three rows at a time in straight bond. Flat tiles should be laid in broken bond. Refer to Figure 32

Work according to the chalk lines marked during setting out. The chalk lines will assist in keeping the vertical rows of tiles in straight parallel lines.

Tiles must be laid loose and not tight against each other to allow for thermal movement.

Certain tiles, such as flat tiles, must be laid in a broken bond, requiring half tiles in every second course at the gable ends. Refer to Figure 32

These tiles, due to their flat design, do not have the inherent strength of profiled tiles and may be damaged or broken if walked upon after installation. Care should therefore be taken when carrying out maintenance work. For further information on these tiles contact the relevant manufacturers.

Nailing or clipping tiles and fixing of storm clips where appropriate must be carried out as the work proceeds. For detailed information on appropriate fixing methods refer to Section 2 for roof pitch, wind forces and nailing recommendations.

Nails used for the fixing of tiles should be non-corrosive clout nails of sufficient length to penetrate the battens to a depth of at least 25mm.





Figure 31: Laying of tiles-straight bond



Legend

- 01 – Roof tile
- 02 – Taper ridge
- 13 – Chalk line
- 14 – Striking chalk line
- 16 – Batten
- 32 – Fascia

Figure 32: Laying of tiles-broken bond

3.5 Eaves

The first course of tiles at the eaves must be in the same plane as the remainder of the roof. To achieve this it must be supported by a continuous tilting batten and not by fascia board only. The average tilting dimension at the eaves course is $\pm 14\text{mm}$. This dimension can be checked by placing a straightedge over the last three courses of tiles. Refer Figure 34

Eaves can either be closed or open. In

exposed and high wind areas, it is recommended to lose off the eaves to prevent tiles from being blown off the roof. Under 26° pitch the underlay must be supported between the tilting batten and the first batten.

If no fascias or gutters are used, the rafter should be cut at right angles so that rainwater discharging from the tiles will not rot the rafter ends. Refer to Figure 35




Figure 33: Ventilalted closed eaves




Figure 36: Eaves flush with wall




Figure 34: Eaves course must neither tilt nor droop




Figure 37: Eaves with concealed gutter




Figure 35: Open eaves

Legend

- | | |
|---------------------|---------------------------------|
| 01 – Roof tile | 43 – Undertile membrane |
| 16 – Batten | 47 – Undertile membrane support |
| 17 – Tilting batten | 48 – Gutter |
| 22 – Rafter | 58 – Cover flashing |
| 23 – Tie Beam | 60 – Masonry wall |
| 26 – Wall plate | 69 – Straight edge |
| 30 – Timber support | |
| 31 – Timber framing | |
| 32 – Fascia | |
| 37 – Eaves lining | |

3.6 Valleys

The size of the valley gutter will depend on the area of the roof section which discharges rainwater to the valley gutter. Valleys can either be closed or preferably open to avoid blockages by leaves etc. stopping the flow of water. Refer to Figures 38-40

The tiles on both sides of the valley must be neatly cut, holed and secured to the counterbatten by means of baling wire.

Where a valley forms a junction between two roof slopes of different pitches (known as a bastard valley), a special valley gutter is recommended. Refer to Figure 42

The raised section in the centre of the valley gutter is to prevent water discharging from the steeper slope of the roof from spilling over the apron of the gutter on the shallower slope of the roof. This should be a minimum of 75mm high.




Figure 38: Open valley




Figure 39: Open valley with preformed gutter

Legend

- 01 – Roof tile
- 16 – Batten
- 20 – Valley counter batten
- 22 – Rafter
- 27 – Valley rafter
- 40 – Fixing nail
- 43 – Undertile membrane
- 45 – Underlay strip
- 53 – Valley gutter




Figure 40: Open valley with special gutter




Figure 41: Closed valley with preformed gutter




Figure 42: Bastard valley with special gutter

Legend

- 01 – Roof tile
- 16 – Batten
- 20 – Valley counter batten
- 22 – Rafter
- 27 – Valley rafter
- 40 – Fixing nail
- 43 – Undertile membrane
- 45 – Underlay strip
- 53 – Valley gutter

3.7 Ridges

a) Tapered ridge tiles

A 150mm wide strip of damp-proof course sheeting is recommended under the ridge overlapping the top course of tiles by at least 25mm on either side. Set out the full ridge length before bedding the ridge tiles in mortar. Tapered ridge tiles have a variable overlap and no cutting is required. By increasing the overlap slightly between the ridge tiles the whole ridge can be covered with full tiles. Place mortar on the top course of tiles to form a continuous bed into which the ridge tiles are bedded. The ridge tiles should overlap the top course of tiling by at least 75mm. Solid bed the end ridge tiles at gable ends, using mortar inset with broken pieces of tile, neatly pointed at fair ends.




Figure 43: Tapered ridge

Neatly cut and mitre ridge tiles at intersections with hip etc. Cut off excess mortar and smooth with a wet brush.

b) Butt ridge tiles

Edge bed the butt ridge tiles and solid bed at the joints in mortar over a strip of damp proof course sheeting. As in (a) the joints between the ridge tiles must be filled with mortar supported by broken tile pieces, struck flush with the ridge tiles and wet brushed to a smooth finish. Cut and mitre the tiles where necessary. At the gable ends fill with mortar inset with broken tile pieces cut off excess mortar and smooth with a wet brush.




Figure 43a: Butt ridge




Figure 44: Overlapping monoridge




Figure 45: Butt monoridge

c) Butt Monoridge tiles

Butt monoridge tiles must be edge-bedded in mortar on the top course of roof tiles over a strip of damp proof course. The damp proof course should be bent over and taken down inside the vertical leg of the monoridge. The vertical leg of the monoridge must be fixed with non-corrosive screws or nails. The joints between the monoridges must be filled with mortar supported on broken tile pieces, struck flush with the monoridges and wet brushed to a smooth finish. The monoridges must be neatly cut and mitred at intersections with verges. The ends must be filled with mortar, struck flush with the verge tiles and wet brushed to a smooth finish.

d) Capped monoridge tiles

Capped monoridges are fixed in the same manner as butt monoridges. The capped ends

and at intersections with verges must be filled with mortar, struck and wet brushed to a smooth finish.

e) Ventilated ridge tiles

Where ventilated ridge tiles are installed an opening must be made in the underlay under each ventilated ridge to allow a free flow of air.

Note:

Mortar

Mortar for bedding and pointing for ridges and hips should consist of 3 parts clean plaster sand to one part of Portland cement tinted with an inorganic pigment to blend in with the colour of the roof tiles.

All fittings to be bedded in mortar should be soaked in water to ensure a good bond.




Figure 46: Section through overlapping monoridge




Figure 47: Section through monoridge/
soffit lining

Legend

- | | |
|-----------------------|---------------------|
| 01 – Roof tile | 22 – Rafter |
| 02 – Taper ridge | 32 – Fascia |
| 03 – Butt ridge | 38 – Soffit lining |
| 04 – Verge tile | 40 – Fixing nail |
| 06 – Ventilated ridge | 43 – Undertile |
| 07 – Monopitch ridge | membrane |
| 10 – Fixing point | 46 – Overlay strip |
| 11 – Mortar bed | 60 – Masonry wall |
| 12 – Mortar joint | 68 – DPC 150mm wide |
| 16 – Batten | 70 – Mortar closure |




Figure 48: Section through ventilating ridge

3.8 Hips

Tiles of the main roof must be cut closely to the rake of the hip. Refer to Figure 49. The hips can be covered with either overlapping or butt-jointed ridge tiles and edge-bedded as described for ridge tiles.

a) Hips using taper ridge tiles

When used on hips taper ridge tiles are suitable for any pitch of roof up to vertical.

At vertical hips and pitches above 45° all ridge tiles must be mechanically secured in addition to bedding in mortar. To secure the ridge tiles additional battens must be fixed on top of the hip rafter to form a hip tree of sufficient height to permit the mechanical fixing of the ridge tiles. Refer Figure 51

The taper ridge tiles are fixed in the overlap by nailing to the hip tree using non-corrosive nails. Cutting of ridge tiles can usually be eliminated as the tiles have a variable overlap. Only the end ridge tile which forms an intersection with the ridge is mitred to fit and solid-bedded in mortar. The taper ridge tiles are

edge-bedded in mortar which is struck off and wet brushed to a smooth finish.

Hip irons must be used at pitches above 45° to secure the hip starter to the hip tree using two non corrosive nails or screws. Hip irons are bent to shape using 32mmx3mm galvanised steel. Refer to detail of hip iron Figure 51

b) Hips using butt ridge tiles

When used on hips, butt ridge tiles should only be used on roof pitches below 45°. They must be edge bedded in mortar and solid-bedded at the joints. The mortar at the joints is truck flush with the top of the ridge tile and wet brushed to a smooth finish. Hip irons are recommended to secure the starter ridge tiles.

Purpose-made hip starters should be used at the start of each hip. Alternatively the first ridge tile can be shaped to line up with the eaves courses and must be solid-bedded with mortar inset with broken tile filler pieces and pointed at the fair end. Refer to Figure 50




Figure 49: Hip using taper ridge/hip starter




Figure 50: Hip using butt ridge




Figure 51: Section through hip showing hip tree and hip iron

Legend

01 – Roof tile	22 – Rafter
02 – Taper ridge	28 – Hip rafter
03 – Butt ridge	29 – Hip tree
05 – Hip starter	43 – Undertile membrane
11 – Mortar bed	68 – DPC 150mm wide
12 – Mortar joint	70 – Mortar closure
16 – Batten	

3.9 Verges

Verge tiles must be mechanically fixed on the vertical face to a 38x50mm counterbatten placed on edge with non-corrodible screws or serrated nails.

With bold-contoured roof tiles the verge counter batten must be raised above the batten line to ensure good fixing of the verge tiles. Refer to Figure 52

With standard profile of roof tiles the verge counterbatten must be positioned flush with the top of the tiling battens. Refer to Figure 53

The first verge tiles should have a 25mm tilt at the start to compensate for the overlap

and obtain the correct alignment. This is achieved by extending the fascia board or the tilting batten by 25mm. Refer to Figures 54 and 55




Figure 52: Verge counter batten – bold profile




Figure 53: Verge counter batten – flat profile




Figure 54: Verge detail with fascia




Figure 55: Verge detail without fascia




Figure 56: Flush verge




Figure 57: Overhanging verge with closed soffit

Legend

01 – Roof tile	22 – Rafter
04 – Verge tile	32 – Fascia
16 – Batten	38 – Soffit lining
17 – Tilting batten	40 – Fixing nail
18 – Counter batten	43 – Undertile membrane
19 – Verge counter batten	60 – Masonry wall

The verge can either be a flush verge, Refer to Figure 56, or an overhanging verge. Refer to Figure 57

In exposed areas it is recommended that the verges should be closed. The undertile membrane should therefore be extended to the full overhang of the verge.

The first verge tile is positioned to abut against the second course of tiles. Mark the front side to line up with the eaves course and cut to the required length. Refer to Figures 58 to 59

Thereafter, each following verge tile is fitted butting against the next course of tiles above and overlapping the verge tile below. Refer to Figure 61

The top verge tiles are mitred with the ridge tile and bedded to form a neat secure joint. Refer to Figure 60




Figure 60: Verge/ridge junction




Figure 58: First verge tile




Figure 61: Illustrating positions of verge tiles




Figure 59: Cut first verge tile

Legend

- 01 – Roof tile
- 02 – Taper ridge
- 04 – Verge tile
- 05 – Hip starter
- 10 – Fixing point
- 32 – Fascia
- 65 – Off-cut

3.10 Abutments and Flashings

Adequate flashing must be provided where roof tiling meets abutments, protrusions and where changes in roof pitch occur. The flashing material must be weather resistant and durable. The correct choice of flashing material depends on the corrosion risk.

Materials considered suitable for flashing are zinc, zinc alloy, aluminium alloy, galvanised iron, copper and lead. The flashing and cover flashing should be of the same material to avoid any electrolytic corrosion.

Table 11: Recommended flashing material

Material	Thickness mm
Galvanised iron	0,6
Aluminium	0,5
Zinc alloy	0,6
Lead	1,0

It should be noted however, that aluminium and galvanised steel react to some degree when in contact with cement based products, mortar and plaster. To prevent any reaction it

is recommended that two coats of bituminous or any other suitable paint be applied to the contact surfaces.

a) Apron flashing

Flashing material should be dressed over the tiles and fixed to the wall face, overlapping the tiles by at least 150mm. A suitable material would be lead as it is easily dressed into the profile of the roof tiles. Refer to Figure 62

b) Side flashing

Flashing material must be dressed over the tiles and fixed against the wall face. It must be carried over the first tile contour into the pan of the roof tile. The undertile membrane should be carried up above the roof tiles. Refer to Figure 63

c) Concealed gutter flashing

The preformed gutter must be supported by a timber fillet and fixed against the wall face. Refer to Figure 64




Figure 62: Apron flashing




Figure 64: Concealed gutter flashing




Figure 63: Side flashing

Legend

- | | |
|-------------------------|-------------------------|
| 01 – Roof tile | 50 – Concealed gutter |
| 16 – Batten | 55 – Apron flashing |
| 22 – Rafter | 56 – Side wall flashing |
| 30 – Timber support | 58 – Cover flashing |
| 43 – Undertile membrane | 60 – Masonry wall |

d) Back gutter

The size of the back gutter should be calculated in relation to its length and the volume of water it will receive. It should be at least 200mm wide and have minimum thickness of 0,6mm flashing material.

The detail for the undertile membrane, battening and overhang of the tiles into the gutter should be the same as the eaves detail. A timber fillet, cut to shape, must be installed to support the back gutter. Refer to Figure 65

e) Box gutters

The box gutter must be supported by a continuous timber support. The underlay from the roof must extend into the gutter and the tiles must be tilted up to the wall and should be in the same plane as the roof. To prevent any water entering between the gutter and the masonry wall, special attention should be given to the cover flashing which must be cut into the wall, wedged and sealed, the vertical leg extending into the gutter and sealed against the side wall of the gutter.





Figure 65: Back gutter



Legend

- 01 – Roof tile
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 26 – Wall plate
- 30 – Timber support
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 49 – Box gutter
- 52 – Chimney back gutter
- 58 – Cover flashing
- 60 – Masonry wall

Figure 66: Box gutter

f) Chimney flashing

Flashing to chimney stacks comprises apron flashing, side flashing, cover flashing and back gutter flashing. Lead is the most suitable material for chimney flashings as it lends itself to close dressing at angles and the contours of the roof tiles. When a more rigid material is used, care should be taken at the watershed points of the back gutter to ensure a completely waterproof junction.

For the chimney back gutter, full timber support must be provided. Refer to Figures 67-70




Figure 69: Back/side wall flashing




Figure 67: Apron flashing




Figure 70: Chimney cover flashing



Figure 68: Apron/side flashing

Legend

- 01 – Roof tile
- 55 – Apron flashing
- 56 – Side wall flashing
- 57 – Back gutter flashing
- 58 – Cover flashing
- 61 – Chimney stack

g) Vent pipes

Preformed fittings for vent pipes and other similar protrusions are available. Alternatively lead can be used successfully. Refer to Figures 71 and 72

h) Mansard roofs

Mansard is a form of roof in which two slopes, the lower roof being steeper than the upper roof, meet. At the intersection of the two roof planes where purpose-made tiles are not used, the tiles should be nailed and clipped. Lead flashing should be installed to prevent wind-driven rain from entering into the roof space. If the tiles are positioned correctly at the junction, the weatherhead of the upper tile will form a perfect closure with the tile beneath it. Refer to Figure 73




Figure 73: Mansard roof




Figure 71: Vent pipe flashing




Figure 74: Change in pitch of roof




Figure 72: Vent pipe through roof

Legend

01 – Roof tile	43 – Undertile membrane
08 – Storm clip	54 – Flashing
16 – Batten	66 – Vent pipe
17 – Tilting batten	67 – Vent pipe flashing
22 – Rafter	

i) Change in pitch

Where a change in the roof pitch occurs (as in the case of a sloping dormer) sheet lead flashing should be placed at the intersection. It should be dressed over the contours of the lower tiles and turned up under the upper tiles. Refer to Figure 74

j) Skylights

The treatment for skylights should be similar to that described for abutments and chimneys.

3.11 Inspection after Tiling

- Roof level across the plain. No sagging visible (especially at eaves tiles)
- Roof pitch, truss spacing and batten spacing according to specification
- Fixing of tiles carried out in accordance with recommendations in the Concrete Manufacturers Association "Technical and Detailing Manual for Concrete roof tiles"
- Undertile membrane properly installed (especially at closed eaves)
- All parapet walls and abutments completed
- Flashing to parapet walls, abutments and protrusions such as vent pipes properly carried out.
- Beam filling completed
- Ridge and hip tiles properly bedded in mortar and jointing mortar tinted to match roof tiles. Hip iron installed when required.
- Hip and ridge tiles neatly cut at junctions and solid bedded
- Tiles in valleys neatly cut and properly secured
- Verge tiles secured to verge counter-batten
- Roof left perfect and watertight on completion. All gutters and valleys cleaned out
- All cracked tiles replaced
- All tiles to be in straight courses horizontally and vertically

Concrete Roof Tiles

Section 4 Roof Detailing

Section 4: Detailing

	CONTENTS	COMPUTER REFERENCE NUMBER	PAGE
4.1	Preface		80
4.2	BAtten positions	RT-BA-01/03	81
4.3	UNdertile membrane	RT-UN-01/04	82
4.4	CCondensation and VVentilation	RT-CV-01/02	85
4.5	EAVes	RT-EA-01/05	86
4.6	VAlleys	RT-VA-01/05	89
4.7	RIldges	RT-RI-01/07	92
4.8	HIps	RT-HI-01/03	95
4.9	VErges	RT-VE-01/06	97
4.10	Abutments and Flashings	RT-AF-01/06	99
4.11	Special Roofs	RT-SR-01/02	101

4.1 Preface


The purpose of this section of the CMA's concrete roof tile manual is to provide guidelines for the detailing of concrete roof tiles.

It should be read in conjunction with the technical section of the manual. The National Building Regulations and the relevant South African Bureau of Standards specification and codes of practice


The details given in the manual are also available on various CAD systems.

The computer reference number is the file name under which the drawing is saved.


4.2 Batten Positions



RT-BA-01: Eaves batten position with fascia



RT-BA-02: Eaves batten position without fascia



RT-BA-03: Ridge batten position

RT-BA-NB

Notes:


Position of the first batten must be accurately established to ensure the correct overhang of the roof tiles into the gutter.

The top battens at the ridge must be positioned 25mm (for flat profile 25-50mm – refer to the manufacturer) from the roof apex to ensure maximum overlap of the ridge tiles over the top courses of roof tiles.

Legend

- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 32 – Fascia
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 63 – Tilting dimension


4.3 Undertile Membrane Details



RT-UN-01: Undertile membrane over pitched roof illustrating laps

Legend

- 16 – Batten
- 17 – Tilting batten
- 19 – Verge counter batten
- 21 – Truss
- 43 – Undertile membrane
- 44 – Undertile membrane overlap
- 60 – Masonry wall



RT-UN-02: Undertile membrane over boarded roof illustrating laps

RT-UN-NB

Notes:

Undertile membrane must comply with type E of SANS 952-1985 or hold an Agrément certificate as recommended and have a nominal thickness of 250 microns (0,25mm).

Undertile membrane is recommended at all pitches in all areas.

It is mandatory for roof pitches below 26° and above 45° and for all pitches in coastal and other exposed and windy areas.

Undertile membrane overlap 150mm minimum.

Side undertile membrane overlap always over rafter.

Extra undertile membrane material is required in the following areas:


Hips – 600mm wide strip over the main roof undertile membrane

Valleys – 600mm wide strip under the main roof undertile membrane


Legend

- 16 – Batten
- 17 – Tilting batten
- 18 – Counter batten
- 22 – Rafter
- 36 – Boarding
- 43 – Undertile membrane
- 44 – Undertile membrane overlap

4.3 Overlay and Underlay Strips



RT-UN-03: Hip 600mm overlay strip




RT-UN-04: Valley 600mm underlay strip


Legend

- 21 – Truss
- 22 – Rafter
- 43 – Undertile membrane
- 45 – Underlay strip
- 46 – Overlay strip

4.4 Condensation and Ventilation



RT-CV-01: Ventilated closed eaves



RT-CV-02: Open eaves with airbrick

RT-CV-NB


Notes:

Condensation can be prevented by the provision of adequate ventilation of the roof space at eaves, ridges and gable ends. This will ensure an efficient flow of air by convection even if no external air movement is present. Refer to Detail RT-RI-06, illustrating the ventilating ridge tile.


Legend

- 01 – Roof tile
- 08 – Storm clip
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 30 – Timber support
- 32 – Fascia
- 37 – Eaves lining
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 48 – Gutter
- 62 – Air brick

4.5 Eaves Details



RT-EA-01: Ventilated closed eaves



RT-EA-02: Tilting of eaves

RT-EA-NB


Notes:

The average tilting dimension at the eaves course is about 14mm. This dimension can be checked by placing a straight-edge over the last three courses of the tiles to ensure that all tiles lie in the same plane without a tilt or a droop.


Under 26° the undertile membrane should be supported to prevent ponding between the fascia thus allowing a free flow of water into the gutter.

Legend

- 01 – Roof tile
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 30 – Timber support
- 31 – Timber framing
- 32 – Fascia
- 37 – Eaves lining
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 48 – Gutter
- 60 – Masonry wall
- 69 – Straight edge




RT-EA-03: Open eaves



Legend

- 01 – Roof tile
- 08 – Storm clip
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 23 – Tie-beam
- 26 – Wallplate
- 32 – Fascia
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 48 – Gutter
- 60 – Masonry wall

RT-EA-04: Eaves flush with wall



RT-EA-05: Eaves with concealed gutter

RT-EA-NB

Notes:

Eaves can either be closed or open. In exposed and high wind areas, it is recommended that the eaves be closed off to prevent tiles from being blow off the roof. Under 26° pitch the undertile membrane must be supported by the eaves.

If no fascias or gutters are used, rafters should be cut at right angles so that rainwater discharging from the tiles will not rot the rafter ends. Refer to Detail RT-EA-03, page 69.


With concealed gutters special attention must be given to the size of gutter and outlets in relation to the area of the roof.

Allowance should be made for an emergency overflow outlet in case of the gutter becoming blocked.


Legend

- 01 – Roof tile
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 26 – Wallplate
- 31 – Timber framing
- 32 – Fascia
- 37 – Eaves lining
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 48 – Gutter
- 58 – Cover flashing
- 60 – Masonry wall

4.6 Valley Details




RT-VA-01: Open valley with valley gutter




RT-VA-02: Open valley with preformed gutter

Legend

- 01 – Roof tile
- 16 – Batten
- 20 – Valley counter batten
- 22 – Rafter
- 27 – Valley rafter
- 40 – Fixing nail
- 43 – Undertile membrane
- 45 – Underlay strip
- 53 – Valley gutter




RT-VA-03: Open valley with special gutter



RT-VA-04: Closed valley with preformed gutter

Legend

- 01 – Roof tile
- 16 – Batten
- 20 – Valley counter batten
- 22 – Rafter
- 27 – Valley rafter
- 40 – Fixing nail
- 43 – Undertile membrane
- 45 – Underlay strip
- 53 – Valley gutter



Legend

- 01 – Roof tile
- 20 – Valley counter batten
- 27 – Valley rafter
- 40 – Fixing nail
- 43 – Undertile membrane
- 45 – Underlay strip
- 53 – Valley gutter

RT-VA-05: Bastard valley with special gutter

RT-VA-NB


Notes:

The size of the valley gutter will depend on the area of the roof section which discharges rainwater into the valley gutter and must be at least 300mm wide. For large roof areas, the valley gutter must be increased to 450mm or 650mm.


Where a valley forms a junction between two roof slopes of different pitches (known as a bastard valley), a special valley gutter is required. Refer to Detail RT-VA-05.

The raised section in the centre of the valley gutter which is a minimum of 75mm high is to prevent water coming down from the steeper slope of the roof from spilling over the valley gutter on to the shallow slope of the roof.

4.7 Ridge Details




RT-RI-01: Tapered ridge




Legend

- 01 – Roof tile
- 02 – Taper ridge
- 04 – Verge tile
- 07 – Monopitch ridge
- 10 – Fixing point
- 11 – Mortar bed
- 16 – Batten
- 22 – Rafter
- 43 – Undertile membrane
- 68 – DPC 150mm wide
- 70 – Mortar closure


RT-RI-02: Monopitch ridge using overlapping monoridge



RT-RI-03: Monopitch ridge using butt jointed monoridge




RT-RI-04: Section through overlapping monoridge




RT-RI-05: Section through monoridge/soffit lining

Legend

- 01 – Roof tile
- 04 – Verge tile
- 07 – Monopitch ridge
- 10 – Fixing point
- 11 – Mortar bed
- 12 – Mortar joint
- 16 – Batten
- 22 – Rafter
- 32 – Fascia
- 38 – Soffit lining
- 40 – Fixing nail
- 43 – Undertile membrane
- 60 – Masonry wall
- 70 – Mortar closure



RT-RI-06: Ventilating ridge



RT-RI-07: Butt ridge

RT-RI-NB

Notes:

Ridges:

Ridge tiles are either tapered ridges or 120° butt ridges. Prior to bedding in mortar, a strip of DPC must be placed under the ridge tiles so that it overlaps the top course of roof tiles on either side of the roof by at least 25mm. The ridge tiles are then edge-bedded into a continuous bed of mortar which is placed onto the top courses of the roof tiles. Butt ridges to be solid bedded at butt joints only.


Monopitch ridges:

Monopitch ridges are available with overlapping collars or butt-jointed. Ridge tiles must be edge-bedded with mortar which is placed over the DPC strip on the top course of tiles. Mechanical fixing with non-corrosive screws or serrated nails is recommended on the vertical face of the monopitch ridge tile.


Legend

- 01 – Roof tile
- 03 – Butt ridge
- 06 – Ventilated ridge
- 11 – Mortar bed
- 16 – Batten
- 22 – Rafter
- 43 – Undertile membrane
- 68 – DPC 150mm wide

4.8 Hip Details




RT-HI-01: Overlapping ridge with hip starter




Legend

- 01 – Roof tile
- 02 – Taper ridge
- 03 – Butt ridge
- 05 – Hip starter
- 12 – Mortar joint
- 22 – Rafter
- 28 – Hip rafter
- 70 – Mortar closure

RT-HI-02: Butt ridge



RT-HI-03: Hip with hip tree



Detail of hip iron

Legend

- 01 – Roof tile
- 02 – Taper ridge
- 11 – Mortar bed
- 16 – Batten
- 22 – Rafter
- 28 – Hip rafter
- 29 – Hip tree
- 43 – Undertile membrane
- 68 – DPC 150mm wide

RT-HI-NB

Notes:

Overlapping or butt-ridge tiles are used for hips.

On steep pitches, in addition to bedding in mortar, all ridge tiles should be mechanically fixed. The fixing of the overlapping ridge tiles is concealed as they are fixed in the overlap. On steep and vertical pitches butt ridge tiles should not be used.

Hip starters should be used at the start of each hip.


Alternatively, the first ridge tile can be shaped to line up with the eaves courses and solidly bedded in mortar with broken tile filler pieces and pointed at the fair end. At vertical hips and at pitches above 45°, hip irons must be used and additional battens must be fixed on top of the hip rafter to form a hip tree of sufficient height to permit the mechanical fixing of the ridges. Hip irons are usually made of 32 x 3mm galvansied steel and bent to a similar shape as that shown.

Mortar for bedding and pointing should consist of:


3 parts clean plaster sand and 1 part Portland cement, tinted with an inorganic pigment to blend in with the roof tiles

All fittings to be bedded in mortar should be soaked in water to ensure a good bond.


4.9 Verge Details




RT-VE-01: Position of verge counter batten for bold profile tiles



RT-VE-03: Verge counter batten with fascia



RT-VE-02: Position of verge counter batten for all other tiles



RT-VE-04: Verge counter batten without fascia

Legend


- 01 – Roof tile
- 04 – Verge tile
- 16 – Batten
- 17 – Tilting batten
- 19 – Verge counter batten
- 32 – Fascia
- 40 – Fixing nail
- 43 – Undertile membrane

RT-VE-NB


Notes:

All verge tiles must be fixed on the vertical face to the 38 x 50mm verge counter batten with non-corrosive screws or serrated nails. With bold contoured roof tiles the verge counterbatten must be raised above the batten line (Refer to RT-VE-01) to ensure good fixing of the verge tiles. With other profiles of roof tiles, the batten must be positioned flush with the batten line.

To compensate for the overlap, the first verge tile needs a 25mm tilt. This is achieved by extending the fascia by 25mm. Refer to RT-VE-03. Where no fascia is used the tilting batten is extended by 25mm.



RT-VE-05: Flush verge




RT-VE-06: Overhanging verge


Legend

- 01 – Roof tile
- 04 – Verge tile
- 16 – Batten
- 19 – Verge counter batten
- 22 – Rafter
- 40 – Fixing nail
- 43 – Undertile membrane
- 60 – Masonry wall


4.10 Abutments and Flashings



RT-AF-01: Apron flashing



RT-AF-02: Side flashing



RT-AF-03: Concealed gutter flashing

Legend

- 01 – Roof tile
- 16 – Batten
- 22 – Rafter
- 30 – Timber support
- 43 – Undertile membrane
- 50 – Concealed gutter
- 55 – Apron flashing
- 56 – Side wall flashing
- 58 – Cover flashing
- 60 – Masonry wall


RT-AF-NB

Notes:


Where roof tiling meets abutments and protrusions, adequate flashing must be provided. Flashing material must be fixed to the wall face and dressed over the roof tiles.

The cover flashing should be of the same material as the flashing, cut into the wall, wedged and joint sealed.

Provision must be made for an overflow in the event of a blockage in the gutter.



RT-AF-04: Back gutter




Legend


- 01 – Roof tile
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 26 – Wall plate
- 30 – Timber support
- 43 – Undertile membrane
- 47 – Undertile membrane support
- 49 – Box gutter
- 52 – Chimney back gutter
- 58 – Cover flashing
- 60 – Masonry wall

RT-AF-05: Box gutter

4.11 Special Roofs



RT-SR-01: Mansard roof



RT-SR-02: Change in pitch

RT-SR-NB

Notes:

Where a change of pitch occurs in a roof, the intersection between the upper and the lower slope is highly vulnerable to the ingress of water during heavy downpours combined with strong gusts of wind. The upper tiles at this intersection must line up with the lower tiles forming a perfect closure. The flashing should be taken past the tilting batten on the upper slope and dressed into the profile of the tiles on the lower slope.

Legend

- 01 – Roof tile
- 08 – Storm clip
- 16 – Batten
- 17 – Tilting batten
- 22 – Rafter
- 43 – Undertile membrane
- 54 – Flashing

Concrete Roof Tiles

Section 5 Timber Roof Construction

Section 5: Timber Roof Construction

CONTENTS

PAGE

5.1	General information	106
5.2	Timber quality	106
5.3	Timber specification	107
5.4	Timber treatment	107
5.5	Storage of timber	107
5.6	Roof pitch and wind forces	108
5.7	Undertile membrane for roof tiles	109
5.8	Factory engineered trusses	111
5.9	Site manufactured trusses	112
5.10	Erection of trusses	115
5.11	The use of rafters only as roof supports	117
5.12	Fixing of battens	119

5.1 General Information

This section is devoted to timber roof construction, setting out what is considered to be acceptable and established practice in the design and manufacture of timber roof trusses. It is intended as a guide only and does not relieve the designer of the need to make a thorough study in relation to specific designs, site conditions, local authority by-laws and the National Building Regulations.

In South Africa, under the National Building Regulations, there are only two legal methods by which to design and construct timber roofs:

- i) Roof trusses manufactured in accordance with Part L Roofs of SANS 10400 "The Application of the National Building Regulations". This standard outlines the 'deemed to satisfy' requirements for nailed and bolted trusses
- ii The second method is to engage the services of a professional engineer (as required in part B of the National Building Regulations) who would work strictly in accordance with SANS 10160 Loading Code and SANS 10163 "The Structural Use of Timber."

Tacit approval has been given by municipalities in general to pre-fabricated truss fabricators who use a suite of design programs supplied by system suppliers to design roofs up to 10m in span for non public buildings. Most of these system suppliers have been accredited

by the Institute for Timber Construction. Larger buildings and those to whom the public has access are designed under the supervision of professional engineers using the same design programs.

Trusses designed by a competent person in accordance with Part B of the National Building Regulation are not limited to the span, pitch and geometric configuration of trusses specified in Part L of SANS 10400.

The Institute for Timber Construction works closely with both the Timber Division and the Civil Engineering Division of the SABS on grading specifications and design codes for structural timber as well as on matters affecting the National Building Regulations and the application thereof.

The Institute for Timber Construction have instituted a Certificate of Competence scheme for timber truss fabricators who design, manufacture and supply prefabricated nail-plated trusses.

Stringent auditing of the truss fabricators' operations and key personnel before awarding these certificates is an assurance of quality trusses for specifiers and for the general public.

The accuracy and performance of prefabricated timber trusses exceeds that of bolted trusses and cost savings are often significant.

5.2 Timber Quality

All timber used for the construction of roof trusses, rafters and beams should be structural SA pine complying with the requirements of SANS 1783-2/1460/10149, and bear the full standardisation mark. Timber used for roof battens should comply with SANS 1783-4 and bear the full standardisation mark.

Timber used for the construction of roofs on site must be ordered in the dimensions in which it be used and must not be resawn into smaller cross-sectional sizes on site, as this will cause the grade, strength and dimensional tolerances to change.

5.3 Timber Specification

The various grades of timber are defined by different strength properties and allowable design stresses. The grades commercially available are: M4, M5/V5, M6/V6, M7/V7, M8 (limited availability of grade 8).

Table 1: Nominal dimensions of rough-sawn timber

Type	Width mm	Depth mm	Length
Rough-sawn timber	38	38, 50 76, 114 152, 228	From 2700mm to 6600mm in 300mm increments. Some lengths in excess of 3,6m may only have 600mm increments
	50	76, 152 228	
	76	76, 152 228	
SA pine Stocklam (planed)	32 (27) 45 (40) 70 (65) 100 (95) 140 (135)	100mm 600mm in 33,3mm increments	Standard stock lengths are available in 600mm increments up to 18m long

5.4 Timber Treatment

In certain magisterial district in South Africa, it is illegal to use timber for structural purposes, which has not been treated against biological attack. Treatment can be either with CCA or Boron in accordance with SANS 10005 "Treatment of timber."

The districts as listed under Annexure A of Government Gazette No. 10158 27 March 1986 (regulation R602) are illustrated in Figure 1.

5.5 Storage of Timber

Structural timber stored on site should be stacked on level ground on bearers and adequately protected against the weather by covering with a waterproof material. Air must be allowed to circulate through the timber stacks.

Strapping around bundles of battens should not be removed until the battens are to be fixed. This will prevent excessive warping of the battens.



Figure 1: Map of South Africa showing coastal and other areas (shaded) currently requiring treatment of structural South African pine against biological attack

5.6 Roof Pitch and Wind Forces

The roof as a whole should be designed to withstand the minimum design loadings in accordance with SANS 10160. "The general procedures and loading to be adopted in the design of buildings."

When considering wind forces acting on a pitched roof, the pressure on the windward slope is dependent on the pitch. If the pitch is less than 30° , the windward slope may be subjected to severe suction or to negative pressure. If the pitch is steeper than 35° , the roof generally presents sufficient obstruction for a positive pressure to develop on the windward slope but, even in this case, there is an area near the ridge where suction develops. The leeward side is always subject to suction, though it is usually not as strong as the produced near the windward edge. Refer to Figures 2-4

When considering pitches of roofs, conditions such as wind speed, shape and locality of building, height and exposure of the roof must be taken into consideration.

Recommended minimum pitches for the various types of concrete roof tiles are shown in the Manual under Section 2: Technical Data. Where rain and wind conditions are known to be severe, the roof pitch should, as a rule, be increased by 5° above the minimum. Roof pitches below $17,5^\circ$ are not recommended.

Where a roof has a valley construction the pitch of the valley will be less than that of the general roof plane. The pitch of the roof should therefore be increased so that the pitch of the valley is not less than $17,5^\circ$. All valley and hip construction must be designed by a competent professional engineer.

For further information on wind forces, refer to the wind forces section of SANS 10062-2003 "Fixing of concrete interlocking roofing tiles."




Figure 2: Wind forces on flat pitches




Figure 3: Wind forces on steep pitches




Figure 4: Clip fixing / nail fixing

5.7 Undertile Membrane for Roof Tiles




Figure 5: Closed eaves




Figure 6: Open eaves




Figure 7: Overlay strip – hip




Figure 8: Underlay strip –valley

In current building practice, the undertile membrane has become an integral part of any tiled roof. When properly laid, it will provide a highly effective barrier against the ingress of wind-driven rain and dust and the pressures exerted by wind forces will be reduced substantially due to pressure equalisation.

The use of a suitable undertile membrane which complies with requirement type E of SANS 952 – 1985 or Agrément approved having a nominal thickness of 250 microns (0,25mm) is recommended for all pitches in all areas. **It is essential for roof pitches below 26° and above 45° and for all roof pitches in coastal and other exposed and windy areas.**

Undertile membrane must be fixed horizontally over the rafters, prior to battening, with a minimum overlap of 150mm and secured to the centre of the rafters with the minimum number of non-corrosive clout nails. The vertical laps should be secured over the rafters. Do not try and pull the undertile membrane tight.

At closed eaves, the undertile membrane should extend over tilting batten and fascia board to allow drainage of water into the gutter. It should be supported behind the fascia board to prevent it from sagging and forming a water trap. Refer to Figure 5

At open eaves, the undertile membrane should extend at least 20mm over the beam-filling on the exterior wall. Refer to Figure 6

Over a hip, a strip of undertile membrane 600mm wide should be laid overlapping the undertile membrane of the main roof. Refer to Figure 7

In valleys, a similar strip should be used and tucked under the undertile membrane of the main roof. Refer to Figure 8

Legend

01 – Roof tile	43 – Undertile membrane
08 – Storm clip	45 – Underlay strip
16 – Batten	46 – Overlay strip
17 – Tilting batten	47 – Undertile membrane support
21 – Truss	48 – Gutter
28 – Hip rafter	60 – Masonry wall
30 – Timber support	
31 – Timber framing	
32 – Fascia	
37 – Eaves lining	

5.7 Undertile Membrane (continued) Boarded Rafters

In house designs where the boarding or ceiling boards are fixed on top of the rafters, counterbattens must be fixed on top of the ceiling boards directly above the rafters. The undertile membrane should then be laid

horizontally over the counter battens resulting on top of the ceiling boards. The battens are then fixed to the counter battens at the required spacings. Refer to Figure 9

RT-UN-02




Figure 9: Undertile membrane over ceiling illustrating laps

Legend

- 16 – Batten
- 17 – Tilting batten
- 18 – Counter batten
- 22 – Rafter
- 36 – Boarding
- 43 – Undertile membrane
- 44 – Undertile membrane overlap

5.8 Factory Engineered Trusses

A network of prefabricated timber roof truss manufacturers can be found throughout South Africa. These fabricators operate under licence to suppliers of nail-plate connectors and use computer design programs devised by professional engineers.

These fabricators are trained and equipped to offer advice and solutions for any shape of roof, and pitch or span for new structures, or to match existing roofs.

For the purposes of municipal approval, design calculations may be issued in a computer output format, together with the appropriate roof layout, truss diagrams and any explanatory notes.

When placing orders with a truss fabricator, or when a quotation is required, the fabricator must be provided with the following minimum information of a detailed drawing:

- Overall span of roof
- Eaves overhang
- Pitch of roof
- Cantilever distance (if any)
- Truss spacing (can be optimised by the truss engineer) normally 760mm for concrete tiles
- Roofing materials plus any special load
- Ceiling materials, plus any special loads
- Geyser position and capacity
- Hatch openings, size and position
- Special eaves details
- Other details which may affect the design

Typical documentation to accompany truss delivery

Under the Institute for Timber Construction Certificate of Competence scheme, the following is minimum information which is required to be sent to site:

- 1) The roof layout drawings, which must be provided for each project and must show:
 - a) Loading, maximum truss and batten centres.
 - b) The position of the trusses with their marks clearly indicated.
 - c) The positions of the braced bays.
 - d) The type of bracing employed, cross referenced to the bracing details.
 - e) All erection details for hips and valleys.
 - f) The position of any special connections or cleats.
- 2) The relevant bracing details, which must be included with the roof layout drawings.
- 3) Standard notes regarding material specification, sundry timber and bracing connections, nailing and bolting, which should be sent to the site whenever full engineering design drawings are not provided.

For further information and construction details pertaining to good practice in the manufacture, handling, erection and bracing of the roof structure, refer to various publications recommended under APPENDIX B SOURCE DOCUMENTS.

5.9 Site Manufactured Trusses

Roof trusses manufactured on site must comply with the minimum “deemed to satisfy” requirements for nailed and bolted trusses of SANS 10400 “The Application of the National Building Regulations: or be designed by a professional engineer or other competent person.

The requirements of the National Building Regulations are that the truss, single or double pitch, shall be ‘Howe’ type truss with a span not exceeding 10m for double pitch trusses and 6m for single pitch trusses. The trusses must be supported at heel joints only and have bays of equal lengths not greater than 1,5m. Refer to figures 14, 15 and 16

- Where the roof covering is concrete tiles, the size of rafter (top chord), and tie-beam (bottom chord) and the grade of timber to be used shall be selected from Table 2 in such a way that the desired truss span does not exceed the relevant figure.
- All web members shall be at least 38x114mm Grade 4 Timber.
- Where the timber sizes are determined from Table 2, the pitch of the roof shall not be less 17,5°

Table 2: Maximum truss spans for various rafter and tie – beam sizes (Table 1 Part L SANS 10400)

Truss member	Nominal timber size mm	Max span m	
		Timber grade 4	Timber grade 6
Rafter	38 x114	6,0	9,0
	38x152	8,2	10,0
	38x228	10,0	10,0
Tie-Beam	38x114	4,7	6,7
	38x152	5,9	8,5
	38x228	7,2	10,0

a) Truss spacing for concrete tiles

The spacing of roof trusses in accordance with SANS 10400 Part L ‘Roofs’ shall not exceed 760mm from centre to centre using 38x38 mm battens at maximum 345mm centres.

This truss spacing may be increased when using engineered trusses designed by a professional engineer in accordance with

SANS 10163, and using 38x50mm battens to SANS 653 to suit the span as indicated in Table 3.

Table 3: Truss spacing (Concrete roof tiles)

Max Truss Centres mm	Max Batten Centres mm	Size of Battens mm
760	345	38x38
900	345	38x50 flat
1000	345	38x50 on edge

b) Joints in trusses

The number of connecting devices to be used at each intersection between two members at any heel joint or any splice in a truss shall be determined from Table 4.

In the case of any joint other than a heel joint or splice, one 10mm bolt plus three 90x4mm nails shall be used.

Table 4: Number of connecting devices required in heel joints and splices (Table 2 Part L SANS 10400)

Truss Span m	3(90x4mm) nails plus 10mm bolts	16mm bolts only	50mm toothed ring connectors
	No. of Bolts	No. of Bolts	No of Connectors
3	1	1	1
4	2	2	1
5	2	2	1
6	3	2	2
7	3	2	2
8	4	3	2
9	4	3	2
10	5	3	2

c) Manufacture of trusses on site

To ensure a high standard of finish, it is essential that the roof structure is properly constructed. Poor workmanship and warped timber will reflect on the finished product and may result in deflection and distortion of the roof.

- Select a level surface to work on
- Set out the first truss according to span and pitch of the roof
- Mark out the timber for various members of the truss and cut accurately
- Assemble the truss by nailing and bolting through the two thicknesses of timber and

clinch the nails over on the reverse side.

- The bolts must have a washer on either end and should be tightened without crushing the timber under the washers.
- The completed truss can now be used as a jig for the construction of the remaining trusses of the same size.

Note: Trusses can also be manufactured on site to an engineer's design using nail-plate connectors. This method can show substantial savings in timber requirements.




Figure 10: Hip tree

d) Illustrations of hips and valleys

For the construction of hips and valleys the services of a professional engineer should be engaged. This is a requirement of SANS 10400/NBR.

The following are illustrations only of some of the many types of hips and valleys and must not be used for construction purposes.

Where the pitch of a roof exceeds 40° additional battens must be fixed on top of the hip rafter to form a hip tree of sufficient height to permit the mechanical fixing of the ridge tiles. Refer to Figure 10




Figure 11: Hip and jack trusses




Figure 12: Using trusses ranging in spans to form a valley




Figure 13: Valley using valley rafters

Legend

16 – Batten
21 – Truss
22 – Rafter
26 – Wall plate

27 – Valley rafter
28 – Hip rafter
29 – Hip tree
43 – Undertile membrane

e) Typical roof trusses for site manufacture




Figure 14: Howe truss 4 bay




Figure 15: Howe truss 6 bay (can also be 8 bay with a maximum span of 10m)





Figure 16: Half-Howe truss



- Legend
- 22 – Rafter
 - 23 – Tie beam
 - 24 – King post
 - 25 – Web
 - 26 – Wall plate
 - 60 – Masonry wall

Figure 17: Stub end truss (must be designed by a professional engineer)

5.10 Erection of Trusses

Failure of roofs can often be attributed to poor workmanship and the disregard of simple erection procedures.

Trusses should be protected against any damage on site whilst awaiting erection. They should be stacked on level ground on timber bearers and covered with a waterproof material but with adequate ventilation. When handling trusses care must be taken to avoid any damage to the timber and to the joints.

- if possible, carry trusses vertically
- With large trusses, sufficient labour should be made available to provide full support avoiding any sagging or whipping when carrying the truss horizontally
- Do not “see-saw” the truss across the walls or scaffolding
- Lift trusses onto the wall in an upright position.

Erection procedure:

- Lay the wall plates in position and level. Mark truss centres on the wall plates on either side of the building and ensure that they are square with the gable end of the building.
- Lift the first truss onto the marked position on the wall plate. Plumb the truss and secure in the position using temporary props. Refer to Figure 18
- A further two trusses can now be lifted into position, plumbed and fixed temporarily to the first truss using 38x38mm battens fixed on either side of the ridge keeping the trusses in a vertical position. Fix vertical cross bracing to either side of the king post using 38x76mm M4 grade timber, fixing each connection with two no75x3,5mm wire nails. The three trusses attached with cross bracing create a rigid unit to which the other trusses can be attached with temporary battens. These temporary battens and bracing can be removed once all the permanent battens are fixed. Refer to Figure 19
- The remainder of the trusses can be erected, plumbed and attached to the three braced trusses using battens as temporary bracing
- Span a builder's string line across the rafters of the trusses to check alignment and adjust where necessary using hardboard wedges under the tie-beams of the trusses and skew nail all trusses to wall plate with 100mm nails.




Figure 18: Position of first truss




Figure 19: Illustrating vertical cross bracing

Legend

- | | |
|-----------------|--------------------|
| 16 – Batten | 33 – Cross bracing |
| 21 – Truss | 39 – Prop |
| 26 – Wall plate | 60 – Masonry wall |

- f) Permanent diagonal bracing must be installed at the gable ends of the roof. Bracing members must be minimum 38x76mm and should be nailed to the underside of rafters with no. 75x3,5mm wire nails. They must run in a straight line from the apex of the truss to the heel of the truss at approximately 45° and must be connected to the wall plate. Refer Figure 20

For spans greater than 6 metres use 38x114mm (Grade 4) bracing members bolted to the underside of shelf with 2 No M12 bolts. Refer figure 20 detail standard – heel bracing

- g) To prevent buckling of the long webs (exceeding 1,8 metres), cantilever roofs and the tie beam where no ceiling battens are used, longitudinal runners should be fixed to the members. The runners must be 38x76 nailed to each truss with two no. 75x3,5mm wire nails at each intersection. All longitudinal runner members must be cross braced. Refer to Figure 21
- h) Having completed all the necessary bracing the trusses must be permanently anchored to the wall and wall plate with the metal straps or galvanised wire which have been built into the wall. Refer to Figure 22

Note: Refer to SANS 10243 “The Design, Manufacture and Erection of Timber




Figure 20: Diagonal bracing to rafter

Trusses” for an update of bracing details which may supercede the details shown here.

Roof anchorage

To resist any uplift forces, it is essential that every truss or rafter be properly anchored to the supporting wall. This can be carried out by using galvanised steel straps 30x1,6mm or 4mm diameter galvanised steel wire, embedded at least 300mm deep into the wall.

The 4mm diameter steel wire should consist of two strands which should be taken up on either side of the rafter, twisted together and nailed to prevent untwisting.

In the case of timber frame building, any roof truss, rafter or beam shall be securely fastened to the wall construction in accordance with SANS 10082 1988 “Timber Buildings.”




Figure 21: Longitudinal runner and cross bracing to long webs




Figure 22: Roof anchorage

Legend

- | | |
|----------------------------------|-----------------------|
| 21 – Truss | 35 – Diagonal bracing |
| 22 – Rafter | 40 – Fixing nail |
| 26 – Wall plate | 42 – Metal strap |
| 33 – Cross bracing | 60 – Masonry wall |
| 34 – Longitudinal runner bracing | |

5.11 The use of Rafters only as Roof Supports

The use of rafters spanning from wall to wall is a regular feature of modern architecture. The ceiling follows the slope of the roof, or it can be fixed on top of the rafters. Refer to Figure 23

The rafters and wall plate are anchored as previously described, using either 30x1,6mm metal straps or 4mm diameter galvanised wire built into the wall.

The rafters must be designed simply supported and the loading uniformly distributed over the full span, in accordance with SANS 10163 "The Structural Use of Timber." Timber quality is as specified in Section 5.2. Lateral stability for the beams is provided by the tile battens.




Figure 23: Use of rafters

Legend

- 16 – Batten
- 19 – Verge counter batten
- 22 – Rafter
- 60 – Masonry wall

Member sizes for tiled roofs

The following sizes of rafters are for tiled roofs with tiles having a mass of 55kg/m² and are designed for 0,5 kN/m² live load and a light ceiling and for pitches up to 25°. The following criteria has been applied, namely permissible stress and a final deflection of SPAN/200.

The batten spacing is assumed to be less or equal to 360mm. Grade number (Gr#) in the table refers to the grade of timber. Only timber commonly available in commercial quantities is listed.

Table 5: Timber sizes and grades for concrete tiled roofs at maximum spans of rafters

Span of Rafters mm	Spacing of Rafters mm		
	760	900	1000
2000	38 x 152 Gr 4 40 x 128 Lam	38 x 152 Gr 4 40 x 128 Lam	38 x 152 Gr 4 40 x 128 Lam
3000	38 x 228 Gr 4 38 x 152 Gr 7	38 x 228 Gr 4	38 x 228 Gr 4
4000	50 x 228 Gr 5	50 x 228 Gr 5 76 x 228 Gr 4	76 x 228 Gr 4
5000	76 x 228 Gr 4 65 x 195 Lam	65 x 228 Lam	65 x 228 Lam
6000	65 x 261 Lam	65 x 261 Lam	65 x 295 Lam

Note: Batten sizes must be in accordance with Table 3

5.12 Fixing of Battens

Timber used for battens must comply with SANS 1783-4. The battens should be straight, free from major defects and in long lengths. Joints in battens should be staggered on rafters. Size of battens must be in accordance with spacing of trusses. Refer to Table 3.

Batten centres will depend on the type of concrete roof tile which is to be used. For information on the full range of roof tiles refer to manufacturer's literature. The following checks should be carried out before fixing of the battens commences.

Check:

- Trusses for alignment/straightness
- Truss spacing
- Truss anchorage to wall and wall plate
- Pitch of roof
- Construction of hips and valleys to engineer's details
- Bracing of trusses
- Squareness of roof
- Brickwork and plastering to gables, parapets chimney and beam filling has been completed.

Battening procedure:

- Establish the roof eaves overhang. Work out the number of full roof tiles to cover the distance from eaves to ridge. To avoid cutting tiles, adjust the eaves overhang allowing for the thickness of fascia plus 50mm overhang of the first row of tiles past the fascia. Ensure that the last of the battens at the ridge is not more than 25mm (for flat profile 25-50mm-refer to manufacture) from the apex. Refer to Figure 26.
- Trim rafters at the eaves and fix tilting batten and fascia board. Tilting batten to be 14mm higher than the other battens to ensure roof tiles are in the same plane.
- Fix underlay over trusses by nailing, with the minimum number of non-corrosive clout nails, to the centres of the rafters of the trusses. It is not necessary to fix the undertile membrane tightly over the rafters.
- Mark the batten centres at each end of the roof and strike a chalk line.




Figure 24: First batten with fascia




Figure 25: First batten without fascia




Figure 26: Ridge batten position


Legend

- | | |
|-------------------------|---------------------------------|
| 16 – Batten | 47 – Undertile membrane support |
| 17 – Tilting batten | 63 – Tilting dimension |
| 22 – Rafter | |
| 32 – Fascia | |
| 43 – Undertile membrane | |

- e) Fix battens according to the chalk lines allowing sufficient overhang at gable ends for trimming. The length of nails for fixing battens should be batten thickness plus 40mm. For a neat fit where the battens intersect at hips and valleys, the battens should be mitred.
- f) Establish verge overhang using width of full tiles along the eaves and along the ridge. Mark at top and tilting batten only. Strike a chalk line between the two points and cut the battens. Refer to Figure 27

- g) If verge tiles are used, the tilting batten and fascia board must extend past the verge counter batten by 25mm to allow for the tilt in the first verge tile.
- h) With bold profile roof tiles the verge counter batten must be raised above the batten line to ensure good fixing of the verge tiles. Refer to Figure 28
With all the profiles the verge counter batten must be positioned flush with the batten line. Refer to Figure 29

The roof is now ready for tiling.



Legend

- 01 – Roof tile
- 04 – Verge tile
- 10 – Fixing point
- 13 – Chalk line
- 16 – Batten
- 17 – Tilting batten
- 19 – Verge counter batten
- 21 – Truss
- 40 – Fixing nail
- 43 – Undertile membrane
- 60 – Masonry wall

Figure 27: Setting out a verge




Figure 28: Verge counter batten for bold profile tiles




Figure 29: Verge counter batten for all other profiles

Appendix A: Legend

01	Roof tile	36	Boarding
02	Taper ridge	37	Eaves lining
03	Butt ridge	38	Soffit lining
04	Verge tile	39	Prop
05	Hip starter	40	Fixing nail
06	Ventilated ridge	41	Bolt
07	Monopitch ridge	42	Metal strap
08	Storm clip	43	Undertile membrane
09	Hip iron	44	Undertile membrane overlap
10	Fixing point	45	Underlay strip
11	Mortar bed	46	Overlay strip
12	Mortar joint	47	Undertile membrane support
13	Chalk line	48	Gutter
14	Striking chalk line	49	Box gutter
15	Tile stack	50	Concealed gutter
16	Batten	51	Back gutter
17	Tilting batten	52	Chimney back gutter
18	Counter batten	53	Valley gutter
19	Verge counter batten	54	Flashing
20	Valley counter batten	55	Apron flashing
21	Truss	56	Side wall flashing
22	Rafter	57	Back gutter flashing
23	Tie beam	58	Cover flashing
24	King post	59	Soakers
25	Web	60	Masonry wall
26	Wall plate	61	Chimney stack
27	Valley rafter	62	Air Brick
28	Hip rafter	63	Tilting dimension
29	Hip tree	64	Cut-off mark
30	Timber support	65	Off-cut
31	Timber framing	66	Vent pipe
32	Fascia	67	Vent pipe flashing
33	Cross bracing	68	Damp proof course (DPC)
34	Longitudinal runner bracing	69	Straight edge
35	Diagonal bracing	70	Mortar closure

Appendix B: Source Documents

1. MiTek South Africa (Pty) Ltd, Timber Roof Truss System.
2. The Institute for Timber Construction, Timber Truss Manual, Johannesburg: 1993
3. SANS 10062: 2003 Fixing of concrete interlocking roofing tiles, Pretoria: South African Bureau of Standards, 2003.
4. SANS 10082: 1988, Timber buildings, Pretoria: South African Bureau of Standards, 1988.
5. SANS 10163, The structural use of timber:
Part 1: Limit-state design, Pretoria: South African Bureau of Standards, 2003.
Part 2: Allowable stress design, Pretoria: South African Bureau of Standards, 2001.
6. SANS 10400: 1990, The application of the National Building Regulations Pretoria: South African Bureau of Standards, 1990.
7. SANS 1783-2, Sawn softwood timber Part 2: Stress-graded structural timber, Pretoria: South African Bureau of Standards, 2005.
8. SANS 1783-4: 2004, Sawn softwood timber Part 4: Brandering and battens, Pretoria: South African Bureau of Standards, 2004.
9. SANS 10149: 2002, The mechanical stress grading of softwood timber, Pretoria: South African Bureau of Standards, 2002.
10. SANS 1460: 2006, Laminated timber, Pretoria: South African Bureau of Standards, 2006.
11. National building regulations and building standards act, Pretoria: Government Printer, 1977. (Act no. 103 of 1977).
12. SANS 10160: 1989, The general procedures and loadings to be adopted in the design of buildings, Pretoria: South African Bureau of Standards, 1989.
13. SANS 10005: 2006, The preservative treatment of timber, Pretoria: South African Bureau of Standards, 2006.
14. Regulations in terms of the Forest Act, Government Gazette 10158, 27 March 1986, Pretoria: Government Printer, 1986, Annexure A of Regulation R602.
15. SANS 952: 1985, Polyolefin film for damp-proofing and waterproofing in buildings, Pretoria: South African Bureau of Standards, 1985.
16. SANS 10243: 2004. The design, manufacture and erection of timber trusses, Pretoria: South African Bureau of Standards, 2004.
17. SANS 542 – 2004. Standard specification for the manufacture of concrete roofing tiles, Pretoria: South African Bureau of Standards, 2004.
18. Marley Roofing, Professional Concrete Roof Tile Manual.
19. Photographs: Marley Roofing

Notes

[illegible]

Notes

[illegible]

We acknowledge the support
of the following major raw material suppliers:



Published by the
Concrete Manufacturers Association
Block D, Lone Creek
Waterfall Office Park
Bekker Road, Midrand
PO Box 168, Halfway House 1685

Telephone +27 11 805 6742
Facsimile +27 11 315 4683
e-mail main.cma@gmail.com
Website www.cma.org.za

Second edition 2007